



**Unit 4 Denbigh Hall Ind Est, Denbigh Hall, Bletchley, Milton Keynes. Buckinghamshire, MK3 7QT.
Tel: 0908 371929**

Email: info@cdrecycling.co.uk
Website: www.cdrecycling.co.uk

-
- C & D Recycling encourages you to re-use old boxes as you prepare your packages for collection.
 - **IMPORTANT**, we can only collect if you have 20 or more items of the list when sending by box. If you are sending us courier bags, a minimum of 20 or more items from our list are required. We can collect when you have 80 items or more of our list per pallet; this is due to the cost of diesel, courier fuel surcharge, safe disposal under the WEEE Directive, and Environment Agency fees.
 - **Northern Ireland, Republic of Ireland, Isle of Wight and Isle of Man must have 100 or more items of the list (this is strict due to higher cost) all other UK offshore islands we can only collect Inkjets & mobile phones.**
 - C & D Recycling will only credit the charity account if your collection has the minimum required. If you are in any doubt as to the acceptance of any cartridges or mobile phone please call.
 - In general we only collect original cartridges. There is no value for refilled cartridges, compatible cartridges or Epson cartridges (unless otherwise listed). Broken cartridges have no value so please ensure that your items are packed carefully prior to collection.
 - **IMPORTANT**, we cannot currently recycle toner bottles, photocopier bottles, tanks, tubes and ribbon cartridges. If we receive these items, we will have to invoice you 50p each for their safe disposal.
 - Please note that there will be no charges if you work from our list. Please note that collections will be monitored and if high levels of waste items are found to be continually sent back then we will invoice you for the safe disposal.
 - **VERY IMPORTANT, Failed/ unsuccessful collection. We charge £25 + Vat for a failed collection. We are sorry for having to impose these but failed collections are on the increase, so please ensure you let someone else know we are coming to collect or cancel the collection the day before.**
 - **Parcels / Packages – any single item weighing up to 30kgs in weight, and with measurements of not more than 1.0 metre long, 0.60 metres wide and 0.70 metres high or which has a girth (length + height + width) of not more than 2.3 metres. Anything larger or heavier will incur a freight surcharge which we will unfortunately have no choice but pass on**



Inkjets

Brother Inkjets

Brother LC980 Black	LC-980 Black
Brother LC980 Color	LC-980 Cyan
Brother LC980 Color	LC-980 Magenta
Brother LC980 Color	LC-980 Yellow
Brother LC985 Color	LC-985 Black
Brother LC985 Color	LC-985 Cyan
Brother LC985 Color	LC-985 Magenta
Brother LC985 Color	LC-985 Yellow

BT Inkjets

BT	BT 3000 black 15M1690
BT	BT 3000 Color 15M1700
BT	BT 50/55 (yellow top, but not ink tank)
BT M2176	BT 50/55/60/65 (grey top)
BT M2176	BT 50/55/60/65 (orange top)
BT M2191	BT 50E/55E/60E/65E (blue top)
BT (Flat grey or orange top - NOT light blue/grey top)	BT Paperjet 30 / 35

Canon Inkjets

Canon BJ100 / 200 / 220 / 230 / BJC-150 / 210 / 240	BC-02
Canon BJC-150 / 210 / 241	BC-05
Canon B140 / 150 / 160 / 170 / 310 / 320 / 340 / 360	BX-2
Canon FAXPHONE B740	BX-20
Canon FAXPHONE B45, B540, B550, B640, B95, MultiPASS 800	BX-3
Canon Pixma iP1800/2500 Black	No 30 / PG-30
Canon Pixma iP1800/2500 Black	No 31 / PG-31
Canon BCI-320PG Black	No 320 / BCI-320PG Black
Canon BCI-321PG Black	No 321 / BCI-321PG Black
Canon BCI-321PG Cyan	No 321 / BCI-321PG Cyan
Canon BCI-321PG Magenta	No 321 / BCI-321PG Magenta
Canon BCI-321PG Yellow	No 321 / BCI-321PG Yellow
Canon Pixma iP1800/2500 Black	No 37 / PG-37
Canon Pixma iP1800/2500 Color	No 38 / CL-38
Canon IP2200 / IP1600 / MP150 / MP170 / MP450 PIXMA Black Standard	No 40 / PG-40
Canon IP2200 / IP1600 / MP150 / MP170 / MP450 PIXMA Color Standard	No 41 / CL-41
Canon Pixma iP3300/4200/4300 Black	No 5 / PGI-5
Canon MP450 Photo All-In-One and iP6210D, iP6220D Photo Printers	No 51 / CL-51
Canon Pixma MP240/260/480	No 510 / PG-510 Std Cap
Canon Pixma MP240/260/480	No 511 / CL-511 Color
Canon Pixma MP240/260/480	No 512 / PG-512 Hi Cap
Canon Pixma MP240/260/480	No 513 / CL-513 Color Hi Cap
Canon PIXMA iP6220D/iP6210D Photo	No 52 / CL-52
Canon Pixma iP3600 / 4600 Black	No 520 / PGI-520 Black
Canon Pixma iP3600 / 4600 Black	No 521 / CLI-521 Black
Canon Pixma iP3600 / 4600 Color	No 521 / CLI-521 Cyan
Canon Pixma iP3600 / 4600 Color	No 521 / CLI-521 Gray
Canon Pixma iP3600 / 4600 Color	No 521 / CLI-521 Magenta
Canon Pixma iP3600 / 4600 Color	No 521 / CLI-521 Yellow
Canon CLI-525 Black	No 525 / CLI-525 Black
Canon PGI-525 Black	No 525 / PGI-525 Black
Canon CLI-526 Black	No 526 / CLI-526 Black
Canon CLI-526 Cyan	No 526 / CLI-526 Cyan

Canon CLI-526 Grey	No 526 / CLI-526 Grey
Canon CLI-526 Magenta	No 526 / CLI-526 Magenta
Canon CLI-526 Yellow	No 526 / CLI-526 Yellow
Dell Inkjets	
Dell A920 / 720 Black	Dell Series 1 / KF868 Ink Cartridge
Dell A920 / 720 Color	Dell Series 1 / KF869 Ink Cartridge
Dell A920 / 720 Color	Dell Series 1 / N5878 Trial Ink Cartridge
Dell A920 / 720 Black	Dell Series 1 / N5882 Trial Ink Cartridge
Dell A920 / 720 Black	Dell Series 1 / T0529 Ink Cartridge
Dell A920 / 720 Color	Dell Series 1 / T0530 Ink Cartridge
Dell Series 10 / DR747 Color Hi-Cap	Dell Series 10 / DR747 Color Hi-Cap
Dell Series 10 / GM720 Black Std Cap	Dell Series 10 / GM720 Black Std Cap
Dell Series 10 / UN398 Color Std Cap	Dell Series 10 / UN398 Color Std Cap
Dell Series 10 / YY460 Black Hi-Cap	Dell Series 10 / YY460 Black Hi-Cap
Dell Series 10 / YY639 Photo	Dell Series 10 / YY639 Photo
Dell Series 11 / JP451Black Hi-Cap	Dell Series 11 / JP451 Black Hi-Cap
Dell Series 11 / JP453 Color Hi-Cap	Dell Series 11 / JP453 Color Hi-Cap
Dell Series 11 / JP455 Photo	Dell Series 11 / JP455 Photo
Dell Series 11 / KX701 Black Std Cap	Dell Series 11 / KX701 Black Std Cap
Dell Series 11 / KX703 Color Std Cap	Dell Series 11 / KX703 Color Std Cap
Dell Series 15 / UK852 Color Std Cap	Dell Series 15 / UK852 Color Std Cap
Dell Series 15 / WP322 Black Std Cap	Dell Series 15 / WP322 Black Std Cap
Dell A940 / A960 Black	Dell Series 2 / 7Y743 / X0502 Ink Cartridge
Dell A940 / A960 Color	Dell Series 2 / 7Y745 / X0504 Ink Cartridge
Dell Series 21 / X739N Black	Dell Series 21 / X739N No 21R Black
Dell Series 21 / 592-11334 Color	Dell Series 21 / X740N No 21R Color
Dell Series 21 / Y498D / No 21 Black	Dell Series 21 / Y498D / No 21 Black
Dell Series 21 / Y499D / No 21 Color	Dell Series 21 / Y499D / No 21 Color
Dell Series 22 / 592-11328 Black	Dell Series 22 / 592-11328 Black
Dell Series 22 / 592-11330 Color	Dell Series 22 / 592-11330 Color
Dell Series 23 / 592-11312 Black	Dell Series 23 / 592-11312 Black
Dell Series 23 / 592-11314 Color	Dell Series 23 / 592-11314 Color
Dell J743 Black	Dell Series 3 / T0601 Ink Cartridge
Dell J740 Color	Dell Series 3 / T0602 Ink Cartridge
Dell J743 Black	Dell Series 3 / T0722 Ink Cartridge
Dell 540 / Photo	Dell Series 4 / D6605 Ink Cartridge
Dell 922 / 924 / 942 / 944 / 946 / 962 / 964 Photo	Dell Series 5 / J4844 Photo Ink Cartridge
Dell 922 / 924 / 942 / 944 / 946 / 962 / 964 Black	Dell Series 5 / J5566 Ink Cartridge black
Dell 922 / 924 / 942 / 944 / 946 / 962 / 964 Color	Dell Series 5 / J5567 Ink Cartridge Color
Dell 922 / 924 / 942 / 944 / 946 / 962 / 964 Black	Dell Series 5 / M4640 Ink Cartridge black
Dell 922 / 924 / 942 / 944 / 946 / 962 / 964 Color	Dell Series 5 / M4646 Ink Cartridge Color
Dell 922 / 924 / 942 / 944 / 946 / 962 / 964 Black	Dell Series 5 / MJ246 Ink Cartridge black
Dell 725 / 810 / All In One	Dell Series 6 / JF333 Color Ink Cartridge
Dell 966 Black	Dell Series 7 / CH883 Black
Dell 966 Black	Dell Series 7 / CH884 Black
Dell 966 Black	Dell Series 7 / DH828 Black
Dell 966 Color	Dell Series 7 / DH829 Color
Dell 966 Photo	Dell Series 7 / FH214 Photo
Dell Black	Dell Series 8 / MJ264 Black
Dell 926 Black	Dell Series 9 / MK990 Black
Dell 926 Color	Dell Series 9 / MK991 Color
Dell 926 Black	Dell Series 9 / MK992 Black
Dell 926 Color	Dell Series 9 / MK993 Color
Dell 926 Photo	Dell Series 9 / MK995 Photo
HP Inkjets	
HP 840C (black)	HP No 15 / C6615A\D
HP DJ 610/612/640 Black	HP No 20 / C6614A\D
HP DJ 3920/3940/1410 Black	HP No 21 / C9351
HP DJ 3920/3940/1410 Black	HP No 21XL / C9351
HP 400 / 500 series (black)	HP No 26 / 51626A\G
HP DJ 3320/3325/3420/3550 Black	HP No 27 / C8727A
HP DJ F4280 Black	HP No 300 / C639E B LOW VOL

HP DJ F4280 Black	HP No 300 / CC640EE
HP DJ F4280 Black	HP No 300XL / CC641EE
HP Dj 1050 Black	HP No 301 / CH561EE
HP Dj 1050 Black	HP No 301XL / CH563EE
HP 300 series (black)	HP No 33 / 51633M
HP DJ 5400 Series Low Black	HP No 336 / C9362A
HP Photosmart 2570 Fast Black	HP No 337 / C9364E
HP Photosmart 2570 Fast Black	HP No 337 / C9364EE LOW VOL
HP DJ 5740/6520/6540/6540dt/6840 Black	HP No 338 / C8765E
HP DJ 5740/6520/6540/6540dt/6840 Black	HP No 338 / C8765EE LOW VOL
HP DJ 5740/6520/6540/6540dt/6840 High Black	HP No 339 / C8767E
HP DJ D4260/OfficeJet J5780 Black	HP No 350 / CB335E
HP DJ D4260/OfficeJet J5780 Black	HP No 350 / CB335EE LOW VOL
HP DJ D4260/OfficeJet J5780 High Black	HP No 350XL / CB336E
HP Photosmart B8550 C5380,C6380,D5460 Black	HP No 364 / CB316E
HP Photosmart B8550 C5380,C6380,D5460 Photo Black	HP No 364 / CB317E
HP Photosmart B8550 C5380,C6380,D5460 Extra High Black	HP No 364EXL / CB321EE
HP Photosmart B8550 C5380,C6380,D5460 High Black	HP No 364XL / CB321E
HP Photosmart B8550 C5380,C6380,D5460 High Photo Black	HP No 364XL / CB322E
HP 700 / 800 / 1000 / 1100 / 1600 series (black)	HP No 45 / 51645A\G
HP DJ 420ci/cbi/5150/5550c/5552 Black	HP No 56 / C6656A
HP DJ 420ci/cbi/5150/5550c/5552 Black	HP No 56 / C6656G LOW VOL
HP OfficeJet J4580 / J4660 / 4680 Black	HP No 901 / CC563A
HP OfficeJet J4580 / J4660 / 4680 Black	HP No 901XL / CC654A
HP OfficeJet 6000 / 6500 / 7000	HP No 920 / CD971AE Black
HP OfficeJet 6000 / 6500 / 7000	HP No 920XL / CD975AE B
HP Officejet Pro 8000 9500	HP No 940 / C4902 Black
HP Officejet Pro 8000 9500	HP No.940XL / C4906AE B
HP Colors Inkjets	
HP Photosmart A516/432/433	HP No 110 / CB304A
HP DJ 840/843 Color	HP No 17 / C6625A
HP DJ 3920/3940/1410 Color	HP No 22 / C9352
HP DJ 3920/3940/1410 Color	HP No 22XL / C9352
HP 700 / 800 / 1000 / 1100 series (Color)	HP No 23 / C1823A\D
HP DJ 3320/3325/3420/3550 Color	HP No 28 / C8728A
HP DJ F4280 Color	HP No 300 / C642E C LOW VOL
HP DJ F4280 Color	HP No 300 / CC643EE
HP DJ F4280 Color	HP No 300XL / CC644EE
HP Dj 1050 Color	HP No 301 / CH562EE
HP Dj 1050 Color	HP No 301XL / CH564EE
HP DJ 5400 Series Low Color	HP No 342 / C9361A
HP DJ 5740/6520/6540/6540dt/6840 Color	HP No 343 / C8766E
HP DJ 5740/6520/6540/6540dt/6840 High Color	HP No 344 / C9363E
HP DJ 5740/6520/6540/6540dt/6840 Photo	HP No 348 / C9369E
HP DJ D4260/OfficeJet J5780 Color	HP No 351 / CB337E
HP DJ D4260/OfficeJet J5780 High Color	HP No 351XL / CB338E
HP Photosmart B8550 C5380,C6380,D5460 Color	HP No 364 / CB318E
HP Photosmart B8550 C5380,C6380,D5460 Color	HP No 364 / CB319E
HP Photosmart B8550 C5380,C6380,D5460 Color	HP No 364 / CB320E
HP Photosmart B8550 C5380,C6380,D5460 High Color	HP No 364XL / CB323E
HP Photosmart B8550 C5380,C6380,D5460 High Color	HP No 364XL / CB324E
HP Photosmart B8550 C5380,C6380,D5460 High Color	HP No 364XL / CB325E
	HP No 41A / 51641A
HP DJ 420ci/cbi/5150/5550c/5552 Color	HP No 57 / C6657A
HP DJ 420ci/cbi/5150/5550c/5552 Color	HP No 57 / C6657A LOW VOL
HP DJ 420ci/cbi/5150/5550c/5552 Color	HP No 57 / C6657XL
HP DJ 420ci/cbi/5150/5550c/5552 Photo	HP No 58 / C6658A
HP (various models)	HP No 59 / C9359A
HP Officejet G55 / 85 / 95	HP No 78 / C6578A 38 ML XL
HP Officejet G55 / 85 / 95	HP No 78 / C6578D 19 ML LOW VOL
HP OfficeJet J4580 / J4660 / 4680 Color	HP No 901 / CC656A
HP OfficeJet 6000 / 6500 / 7000	HP No 920XL / CD972AE C

HP OfficeJet 6000 / 6500 / 7000	HP No 920XL / CD973AE M
HP OfficeJet 6000 / 6500 / 7000	HP No 920XL / CD974AE Y
HP Officejet Pro 8000 9500	HP No.940XL / C4907AE C
HP Officejet Pro 8000 9500	HP No.940XL / C4908AE M
HP Officejet Pro 8000 9500	HP No.940XL / C4909AE Y
HP Intro Inkjets	
HP DJ 3920/3940/1410 Color	HP No 22 / C9352 INTRO
HP DJ F4280 Black	HP No 300 / CC639EE INTRO
HP DJ F4280 Color	HP No 300 / CC642EE INTRO
HP Photosmart 2570 Fast Black	HP No 337 / C9364E INTRO
HP DJ 5740/6520/6540/6540dt/6840 Black	HP No 338 / C8765EE INTRO
HP OfficeJet 6000 / 6500 / 7000	HP No 920 Black INTRO
HP OfficeJet 6000 / 6500 / 7000	HP No 920 Colors INTRO
Lexmark Inkjets	
Lexmark Pro 805 / 205 / 705 / 905 / S305 / S405 / S505	No 100A / 14N0918 Black
Lexmark Pro 805 / 205 / 705 / 905 / S305 / S405 / S505	No 100XLA / 14N1092 Black
Lexmark Z2300, Z2320, X2650 and X2600 printers	No 14A / 18C2080E
Lexmark Z2300, Z2320, X2650 and X2600 printers	No 15A / 18C2100E
Lexmark i3/Z13/Z23/Z33/Z601/Z605 Black	No 16 / 10N0016 (Round Connector)
Lexmark i3/Z13/Z23/Z33/Z601/Z605 Black	No 16 / 10N0016 (Square Connector)
Lexmark Z35/Z601/Z605 Low Black	No 17 / 10N0217 (Round Connector)
Lexmark Z35/Z601/Z605 Low Black	No 17 / 10N0217 (Square Connector)
Lexmark X3500/4500/Z1400 Black	No 23A / 18C1623E
Lexmark X2500/5490/Z1300 Black	No 28A / 18C1528E
Lexmark X2580/3580/Z1380 Black	No 3 / 18C1530
Lexmark Z815/X5250/5270 Photo	No 31 / 18C0031
Lexmark Z815/X5250/5270 Black	No 32 / 18C0032
Lexmark Z815/X5250/5270 Black	No 34 / 18C0034
Lexmark Z2400, Z2410, Z2420, X3630, X3650, X4630, X4650	No 36A / 18C2150E
Lexmark Z2400, Z2410, Z2420, X3630, X3650, X4630, X4650	No 36XLA / 18C2190E
Lexmark X9350/P350 Series Photo	No 40 / 18Y0340
Lexmark X4800/6570 Black	No 41A / 18Y0341E
Lexmark X9350	No 44 / 18Y0144
Lexmark X9350	No 44XL / 18Y0134
Lexmark P350	No 45 / 18Y0146
Lexmark Z12/22/32/705 Low Black	No 48 / 17G0648
Lexmark X2600 Series, X3600 Series, X4600 Series	No 4A / 18C1954E
Lexmark Z12/22/32/705 Black	No 50 / 17G0050
Lexmark X2690 / X3690 / X4690 / Z2390 / Z2490	No 5A / 18C1970E
Lexmark 3200/5000/5700/5770 Black	No 70 / 12A1970 (Round Connector)
Lexmark 3200/5000/5700/5770 Black	No 70 / 12A1970 (Square Connector)
Lexmark Z11/31/42/43/45/45e Low Black	No 71 / 15M2971
Lexmark 3200/5000/5700/5770 Black	No 75 / 12A1975 (Round Connector)
Lexmark 3200/5000/5700/5770 Black	No 75 / 12A1975 (Square Connector)
Lex X5100/X5130/X5150/X5190/X6150/X6190/X6170/Z55/Z65	No 82 / 18L0032
Lexmark X73/83/Z31/42/43/51/52/53 Photo	No 90 / 12A1990
Lexmark Colors Inkjets	
Lexmark 13619HC	13619HC
Lexmark Color 1070 / 1100 / 2050 / 3000	1380619
Lexmark X2310/2330/2350/Z730/735	No 1 / 18C0781
Lexmark Pro 805 / 205 / 705 / 905 / S305 / S405 / S505	No 100A / 14N0920 Cyan
Lexmark Pro 805 / 205 / 705 / 905 / S305 / S405 / S505	No 100A / 14N0921 Magenta
Lexmark Pro 805 / 205 / 705 / 905 / S305 / S405 / S505	No 100A / 14N0922 Yellow
Lexmark Pro 805 / 205 / 705 / 905 / S305 / S405 / S505	No 100XLA / 14N1093 Cyan
Lexmark Pro 805 / 205 / 705 / 905 / S305 / S405 / S505	No 100XLA / 14N1094 Magenta
Lexmark Pro 805 / 205 / 705 / 905 / S305 / S405 / S505	No 100XLA / 14N1095 Yellow
Lexmark Impact se S308 / Intuition se S508 / Interpret se S408 / Prospect	No 108 / 14N0332E Black
Lexmark Impact se S308 / Intuition se S508 / Interpret se S408 / Prospect	No 108XL / 14N0476E Black
Lexmark Impact se S308 / Intuition se S508 / Interpret se S408 / Prospect	No 108XL / 14N0477E Cyan
Lexmark Impact se S308 / Intuition se S508 / Interpret se S408 / Prospect	No 108XL / 14N0478E Magenta
Lexmark Impact se S308 / Intuition se S508 / Interpret se S408 / Prospect	No 108XL / 14N0479E Yellow
Lexmark P706/ P707/ P700ser Z705/ Z708/ Z700ser / P3150/ P31201	No 19 / 15M2619

Lexmark X2580/3580/Z1380 Color	No 2 / 18C0190
Lexmark X73/83/Z42/43/51/52/53 Color	No 20 / 15M0120
Lexmark X3500/4500/Z1400 Color	No 24 / 18C1624E (Must be the A Type)
Lexmark X3500/4500/Z1400 Color	No 24A / 18C1624E
Lexmark X73/83/Z42/43/51/52/53 Color	No 25 / 5M0125
Lexmark i3/Z13/Z23/Z33/Z601/Z605 Color	No 26 / 10N0026
Lexmark Z35/Z601/Z605 Low Color	No 27 / 10N0227
Lexmark X2500/5490/Z1300 Color	No 29A / 18C1529E
Lexmark Z815/X5250/5270 Color	No 33 / 18C0033
Lexmark (various models)	No 35 / 18C0035
Lexmark Z2400, Z2410, Z2420, X3630, X3650, X4630, X4650	No 37A / 18C2160E
Lexmark Z2400, Z2410, Z2420, X3630, X3650, X4630, X4650	No 37XLA / 18C2200E
Lexmark X4800/6570 Color	No 42A / 18Y0342E
Lexmark X9350 / P350	No 43 / 18Y0143
Lexmark X9350 / P350	No 43XL / 18Y0133
Lexmark Z12/22/32/705 Color	No 60 / 17G0060
Lexmark 3200/5000/5700/5770 Color	No 80 / 12A1980
Lex X5100/X5130/X5150/X5190/X6150/X6190/X6170/Z55/Z66	No 83 / 18L0042
Lexmark 3200/5000/5700/5770 Color	No 85 / 12A1985
Lexmark Z55/65 Color/Photo	No 88 / 18L0000
Neopost Inkjets	
Neopost RJ 25	RJ 25
Neopost RJ 35 (410)	RJ 35
Neopost RJ 35 (413)	RJ 35
Olivetti Inkjets	
Olivetti FaxiLab Series	FJ-31
Olivetti JP150/170/190/250/350/360	FPJ-20 Yell Top
Olivetti JP150/170/190/250/350/361	FPJ-22
Olivetti Any Way Series	IN501
Olivetti Any Way Series	IN502 High
Olivetti Any Way Series	IN503 Photo
Olivetti Any Way Series	IN504 HI CAP
Olivetti Any Way Series	IN506 Photo
Phillips Inkjets	
Philips IPF 131 / 146 / 174 / 176	PFA 421 Blue Top
Philips FaxJet 320 / 325 / 335 / 355 / 365 / 375	PFA-431 Red Top
Philips FaxJet 520 / 525 / 555	PFA-441
Philips FaxJet 531 / MF440 / 450 / 485 / 495 / 500 / 505	PFA-531
Philips Crystal / 600 / 650 / 660 / 665 / 680	PFA-541
Philips Crystal / 600 / 650 / 660 / 665 / 680	PFA-542 HI CAP
Phillips Colors Inkjets	
Philips IPF 131 / 146 / 174 / 176	PFA 424 Blue Top
Philips FaxJet 534 / MF440 / 450 / 485 / 495 / 500 / 505	PFA-534
Philips Crystal / 600 / 650 / 660 / 665 / 680	PFA-544
Philips Crystal / 600 / 650 / 660 / 665 / 680	PFA-546 HI CAP
Philips Crystal / 600 / 650 / 660 / 665 / 681	PFA-548
Pitney Inkjets	
Pitney Bowes 766-E	PB-766-E
Pitney Bowes 797	PB-797
Samsung Inkjets	
Samsung C1	C1
Samsung C10	C10
Samsung C50	C50
Samsung SF-430 / 4700 / SCX-1000 / 1100 / 1150F	C60
Samsung SF-4000 / 4100 / 4200 / 3000 / 3100 / 3200	M10
Samsung SF330 / SF335T / SF331P	M40
Samsung SF370 / SF375TP	M41
Samsung SF-4300 / 4500 / 430 / 4700 / SCX-1100 Black	M50
Samsung M50C	M50C
Samsung SF350 Fax machine	M55
Sharp Inkjets	
Sharp FO-21BC	FO-21BC

Sharp UXBD80	UXB-80B
Sharp UX-B700	UX-C70B
Xerox Inkjets	
Xerox (various models)	8R12591
Xerox (various models)	8R7880
Xerox (various models)	8R7881
Xerox (various models)	8R7882
Xerox (various models)	8R7883
Xerox (various models)	8R7903
Xerox (various models)	8R7904
Xerox (various models)	J6301A
Laser	
Brother Laser	
Brother HL-2030 / 2040 (with cover)	TN-2000 / TN350 With Cover
Brother HL-2035 / 2045 (with cover)	TN-2005
Brother HL2140/2150N/2170W	TN-2110
Brother HL2140/2150N/2170W	TN-2120
Brother HL2240 / HL2240D / HL2250DN / HL2270DW	TN-2210
Brother HL2240 / HL2240D / HL2250DN / HL2270DW	TN-2220 Hi Cap
Brother HL5100 / 5130 / 5140 / 5150	TN-3030 / TN540
Brother HL5100 / 5130 / 5140 / 5150	TN-3060 / TN570
Brother HL5240 / HL5250DN	TN-3130 / TN550
Brother HL5240 / HL5250DN	TN-3170 / TN580
Brother TN 3230	TN-3230
Brother TN 3230 Laser Cartridge With Cover	TN-3230 With Cover
Brother TN 3280	TN-3280
Brother FAX-8650P/ 8750P/9650/9750/9870	TN-6300 / TN430
Brother FAX-8650P/ 8750P/9650/9750/9870	TN-6600 / TN460
Brother HL-1650 / HL - 1670N	TN-7300 / TN530
Brother HL-1650 / HL - 1670N	TN-7600 / TN560
Brother Colors Laser	
Brother HL-2700CN Color Toner	TN-04 Black
Brother HL-2700CN Color Toner	TN-04 Cyan
Brother HL-2700CN Color Toner	TN-04 Magenta
Brother HL-2700CN Color Toner	TN-04 Yellow
Brother HL-4050CN Black	TN-130 Black Std Cap
Brother HL-4050CN Color	TN-130 Cyan Std Cap
Brother HL-4050CN Color	TN-130 Magenta Std Cap
Brother HL-4050CN Color	TN-130 Yellow Std Cap
Brother HL-4050CN Black	TN-135 Black Hi Cap
Brother HL-4050CN Color	TN-135 Cyan Hi Cap
Brother HL-4050CN Color	TN-135 Magenta Hi Cap
Brother HL-4050CN Color	TN-135 Yellow Hi Cap
Brother HL3040CN / HL3070CW / HL8070 / HL8370 / MFC9010CN / MFC9100	TN-210 Black Std Cap
Brother HL3040CN / HL3070CW / HL8070 / HL8370 / MFC9010CN / MFC9100	TN-210 Cyan Std Cap
Brother HL3040CN / HL3070CW / HL8070 / HL8370 / MFC9010CN / MFC9100	TN-210 Magenta Std Cap
Brother HL3040CN / HL3070CW / HL8070 / HL8370 / MFC9010CN / MFC9100	TN-210 Yellow Std Cap
Brother HL3040CN / HL3070CW / DCP9010 / MFC9120CN / MFC9320CW	TN-230 Black Hi Cap
Brother HL3040CN / HL3070CW / DCP9010 / MFC9120CN / MFC9320CW	TN-230 Cyan Hi Cap
Brother HL3040CN / HL3070CW / DCP9010 / MFC9120CN / MFC9320CW	TN-230 Magenta Hi Cap
Brother HL3040CN / HL3070CW / DCP9010 / MFC9120CN / MFC9320CW	TN-230 Yellow Hi Cap
Brother DCP-9055CDN / HL-4140 / 4150 / 4570 / MFC-9460 / 9465 / 9970	TN-320 Black Std Cap
Brother DCP-9055CDN / HL-4140 / 4150 / 4570 / MFC-9460 / 9465 / 9970	TN-320 Cyan Std Cap
Brother DCP-9055CDN / HL-4140 / 4150 / 4570 / MFC-9460 / 9465 / 9970	TN-320 Magenta Std Cap
Brother DCP-9055CDN / HL-4140 / 4150 / 4570 / MFC-9460 / 9465 / 9970	TN-320 Yellow Std Cap
Brother DCP-9055CDN / HL-4140 / 4150 / 4570 / MFC-9460 / 9465 / 9970	TN-325 Black Hi Cap
Brother DCP-9055CDN / HL-4140 / 4150 / 4570 / MFC-9460 / 9465 / 9970	TN-325 Cyan Hi Cap
Brother DCP-9055CDN / HL-4140 / 4150 / 4570 / MFC-9460 / 9465 / 9970	TN-325 Magenta Hi Cap
Brother DCP-9055CDN / HL-4140 / 4150 / 4570 / MFC-9460 / 9465 / 9970	TN-325 Yellow Hi Cap
Brother Drum Laser	
Brother HL-4050CN Drum Unit	DR-130 Drum
Brother HL-2030 / 2040	DR-2000 / DR350 Drum

Brother HL-2030 / 2040	DR-2005 Drum
Brother HL2140/2150N/2170W	DR-2100 Drum
Brother HL2240 / HL2240D / HL2250DN / HL2270DW	DR-2200 Drum
Brother DCP-9010cn / HL-3040cn / HL-3070cw / MFC-9120cn / MFC-9320c	DR-230 Drum Black
Brother DCP-9010cn / HL-3040cn / HL-3070cw / MFC-9120cn / MFC-9320c	DR-230 Drum CYM
Brother DCP-9010cn / HL-3040cn / HL-3070cw / MFC-9120cn / MFC-9320c	DR-230 Drum Magenta
Brother DCP-9010cn / HL-3040cn / HL-3070cw / MFC-9120cn / MFC-9320c	DR-230 Drum Yellow
Brother HL-820, HL-1020, HL-1040, HL-1040DX, HL-1050, HL-1050DX, HL-	DR-300 Drum
Brother HL-1030/1230/1240/1250/1270/1440/1450/1470	DR-3000 / DR510 Drum
Brother DR3100 Drum Unit	DR-3100 / DR520 Drum
Brother DR3200/DR620 Drum Unit	DR-3200 / DR620 Drum
Brother DCP-9055CDN / HL-4140 / 4150 / 4570 / MFC-9460 / 9465 / 9970	DR-320CL Drum
Brother HL-6050 Series	DR-4000 Drum
Brother HL7050 / HL7050N	DR-5500 Drum
Brother HL-1240 1250 1270	DR-6000 / DR400 Drum
Brother HL-1650/1670/1850/1870	DR-7000 / DR500 Drum
Brother 8070P/MFC-9030/70/9160/80	DR-8000 Drum
Brother Intro Laser	
Brother HL-3260 / 3260	Brother TN2210 / TN2220 Intro
Brother HL-2030 / 2040	TN-2000 / TN350 INTRO
Brother HL2140/2150N/2170W	TN-2110 INTRO
Brother HL2140/2150N/2170W	TN-2120 INTRO
Canon Laser	
Canon LBP 3300/3360 (HP49A)	Canon 108/308//708 (HP49A)
Canon LBP 3300/3360 (HP49X)	Canon 108/308//708 (HP49X)
Canon i-SENSYS MF-8180C / LaserShot LBP-5200	Canon 701 Black
Canon i-SENSYS MF-8180C / LaserShot LBP-5204	Canon 701 Black Hi Cap
Canon i-SENSYS MF-8180C / LaserShot LBP-5201	Canon 701 Cyan (Q3960)
Canon i-SENSYS MF-8180C / LaserShot LBP-5205	Canon 701 Cyan Hi Cap
Canon i-SENSYS MF-8180C / LaserShot LBP-5200	Canon 701 Drum
Canon i-SENSYS MF-8180C / LaserShot LBP-5202	Canon 701 Megenta
Canon i-SENSYS MF-8180C / LaserShot LBP-5206	Canon 701 Megenta Hi Cap
Canon i-SENSYS MF-8180C / LaserShot LBP-5203	Canon 701 Yellow
Canon i-SENSYS MF-8180C / LaserShot LBP-5207	Canon 701 Yellow Hi Cap
Canon LBP-2900 / 2900B / 2900i / 3000	Canon 703
Canon M6580/6560/6550/6540/6530	Canon 706
Canon i-SENSYS LBP-5000 / 5100 / 5000	Canon 707 Black (6000A)
Canon i-SENSYS LBP-5000 / 5100 / 5001	Canon 707 Cyan
Canon i-SENSYS LBP-5000 / 5100 / 5002	Canon 707 Magenta
Canon i-SENSYS LBP-5000 / 5100 / 5003	Canon 707 Yellow
Canon i-SENSYS LBP-3360/ 3300	Canon 708 (49A)
Canon i-SENSYS LBP-3360/ 3301	Canon 708H (49X)
Canon LaserShot LBP3460 / LBP3460	Canon 710 Black (11A)
Canon LaserShot LBP3460 / LBP3461	Canon 710H Black (11X)
Canon 711 Black	Canon 711 Black (Q6470A)
Canon 711 Cyan	Canon 711 Cyan
Canon 711 Magenta	Canon 711 Magenta
Canon 711 Yellow	Canon 711 Yellow
Canon i-SENSYS LBP-3010 / 3100	Canon 712 (12A)
Canon i-SENSYS LBP-3250	Canon 713 (36A)
Canon L3000 / L3000IP	Canon 714
Canon 715 Hi Cap	Canon 715 Hi Cap
Canon 715 Std Cap	Canon 715 Std Cap
Canon 716 Black	Canon 716 / (CB540A) Black
Canon 716 Cyan	Canon 716 / (CB541A) Cyan
Canon 716 Yellow	Canon 716 / (CB542A) Yellow
Canon 716 Magenta	Canon 716 / (CB543A) Magenta
Canon i-SENSYS MF-8450C	Canon 717 Cyan
Canon i-SENSYS MF-8450C	Canon 717 Magenta
Canon i-SENSYS MF-8450C	Canon 717 Yellow
Canon i-SENSYS LBP-7200CDN / MF8330Cdn / MF8350Cdn	Canon 718 Black (CC530A)
Canon i-SENSYS LBP-7200CDN / MF8330Cdn / MF8350Cdn	Canon 718 Cyan (CC531A)

Canon i-SENSYS LBP-7200CDN / MF8330Cdn / MF8350Cdn	Canon 718 Magenta (CC533A)
Canon i-SENSYS LBP-7200CDN / MF8330Cdn / MF8350Cdn	Canon 718 Yellow (CC532A)
Canon i-SENSYS LBP-6300dn/6650dn/MF-5840dn/5880dn	Canon 719 Black (53X)
Canon 719H Black (05X)	Canon 719H Black (05X)
Canon 723 Cyan (CE251A)	Canon 723 Cyan (CE251A)
Canon 723 Magenta (CE253A)	Canon 723 Magenta (CE253A)
Canon 723 Yellow (CE252A)	Canon 723 Yellow (CE252A)
Canon 723H Black (CE250X)	Canon 723H Black (CE250X)
Canon i-SENSYS LBP-6000	Canon 725
Canon M PC1210D / PC1230D / PC1270D	Canon Cartridge M
Canon L380 / L400 / PC-D320 / PC-D340 / ImageClass D320 / D340	Canon Cartridge T
Canon FC200 / 300 series / PC300 / 500 / 700 series	Canon E30 / E15 French or Others
Canon FC200 / 300 series / PC300 / 500 / 700 series	Canon E30 / E15 Japan / Chinese Versions
	Canon EP-22 (92A)
	Canon EP-25 (15A)
Canon LBP3200/300N/LDA/LDF Black	Canon EP-27
	Canon EP-32 (96A)
Canon LB3300	Canon EP-508 Std Cap
Canon LBP1760 / LBP-52	Canon EP-52 (27X)
	Canon EP-62 (29X)
	Canon EP-72 (82X)
Canon LBP460 / LBP660 / LBP-AX	Canon EP-A (06A)
	Canon EP-E (98A)
Canon LBP 430 / LBP-PX	Canon EP-P (74A)
	Canon EP-V (03A)
Canon LBP2460 / LBP-WX	Canon EP-W (09A)
Canon FP-250	Canon FP-250
Canon FilePrint 270	Canon FP-270
Canon L700 series / L3300	Canon FX1
Canon L 100 / 120 Fax	Canon FX10 / Type 104
Canon L500 / L600	Canon FX2
Canon L250 / L300 / MultiPASS L60 / L90 / L6000	Canon FX3
Canon L800 / L900	Canon FX4
Canon FX6 L1000	Canon FX6
Canon FX7 LC700 / L2000 / L2000IP	Canon FX7
Dell Laser	
Dell 1100 / 1110	Dell 1100 / J9341
Dell 1100 / 1110	Dell 1100 / J9833
Dell 1130, 1130n, 1133, 1135n	Dell 1130n / 2MMJP Hi Cap
Dell 1130, 1130n, 1133, 1135n	Dell 1130n / 3J11D Std Cap
Dell 1130, 1130n, 1133, 1135n	Dell 1135n / 7H53W Hi Cap
Dell 1130, 1130n, 1133, 1135n	Dell 1135n / P9H7G Std Cap
Dell P1600	Dell 1600N / K4671
Dell P1600	Dell 1600N / P4210
Dell P1600	Dell 1600N / T5870
Dell P1600	Dell 1600N / X5015
Dell 1815dn	Dell 1815 NF485 Std Cap
Dell 1815dn	Dell 1815 RF223 Hi Cap
Dell 2230	Dell 2230 / M797K
Dell 2330d / 2330dn / 2350d /2350dn	Dell 2330DN / DM254 Std Cap
Dell 2330d / 2330dn / 2350d /2350dn	Dell 2330DN / GT163 Std Cap
Dell 2330d / 2330dn / 2350d /2350dn	Dell 2330DN / PK492 Std Cap
Dell 2330d / 2330dn / 2350d /2350dn	Dell 2330DN / PK931 Hi Cap
Dell 2330d / 2330dn / 2350d /2350dn	Dell 2330DN / PK937 Hi Cap
Dell 2330d / 2330dn / 2350d /2350dn	Dell 2330DN / PK941 Std Cap
Dell 2335 / 2355	Dell 2335 / CR963
Dell 2335	Dell 2335 / HX756 HI CAP
Dell 3330	Dell 3330 / P976R
Dell 113X	Dell 592-11531
Dell M5200	Dell M5200 / J2925
Dell M5200	Dell M5200 / N0888
Dell M5200	Dell M5200 / N0893

Dell M5200	Dell M5200 / R0136
Dell M5200	Dell M5200 / R0137
Dell M5200N	Dell M5200N / R0316
Dell M5200N	Dell M5200N K2885
Dell M5210	Dell M5210 / GD531
Dell M5210	Dell M5210 / HD767
Dell M5210	Dell M5210 / PD974
Dell M5210N	Dell M5210 / TD381
Dell M5310N Extra High Yield	Dell M5310 / RD907 X Cap
Dell M5310N Extra High Yield	Dell M5310 / UD314 X Cap
Dell MS2500	Dell MS2500 / 2Y666
Dell MS2500	Dell MS2500 / 2Y667
Dell MS2500	Dell MS2500 / 2Y668
Dell MS2500	Dell MS2500 / 2Y669
Dell MS2500	Dell MS2500 / R0883
Dell MS2500	Dell MS2500 / R0884
Dell P1500	Dell P1500 / 7Y605
Dell P1500	Dell P1500 / 7Y606
Dell P1500	Dell P1500 / 7Y608
Dell P1500	Dell P1500 / 7Y610
Dell P1500	Dell P1500 / R0894
Dell P1500	Dell P1500 / R0895
Dell P1700 / 1700N / 1710 (Must have the 2 guide wheels on each end and seal intact)	Dell P1700 / H3730
Dell P1700 / 1700N / 1710 (Must have the 2 guide wheels on each end and seal intact)	Dell P1700 / J3815
Dell P1700 / 1700N / 1710 (Must have the 2 guide wheels on each end and seal intact)	Dell P1700 / K3756
Dell P1700 / 1700N / 1710 (Must have the 2 guide wheels on each end and seal intact)	Dell P1700 / N3769
Dell P1720 (Must have the 2 guide wheels on each end and seal intact)	Dell P1720 / GR299
Dell P1720 (Must have the 2 guide wheels on each end and seal intact)	Dell P1720 / GR332
Dell P1720 (Must have the 2 guide wheels on each end and seal intact)	Dell P1720 / MV559
Dell P1720 (Must have the 2 guide wheels on each end and seal intact)	Dell P1720 / MW558
Dell P1720 (Must have the 2 guide wheels on each end and seal intact)	Dell P1720 / PY408
Dell P1720 (Must have the 2 guide wheels on each end and seal intact)	Dell P1720 / RP380
Dell W5300 / W5310	Dell W5300 / M2925
Dell W5300 / W5310	Dell W5300 / N2157
Dell W5300 / W5310	Dell W5300 / R0137
Dell M5330	Dell W5330 / NY312
Dell M5330	Dell W5330 / NY313
Dell Colors Laser	
Dell 1230C / 1235	Dell 1230/35 / J069K C
Dell 1230C / 1235	Dell 1230/35 / J506K M
Dell 1230C / 1235	Dell 1230/35 / M127K Y
Dell 1230C / 1235	Dell 1230/35 / N012K B
Dell 1235CN	Dell 1235cn / J506K M
Dell 1235CN	Dell 1235cn / M127K Y
Dell 1320 Black Hi Cap	Dell 1320 Black Hi Cap
Dell 1320 Black Std Cap	Dell 1320 Black Std Cap
Dell 1320 Color Hi Cap	Dell 1320 Cyan Hi Cap
Dell 1320 Color Std Cap	Dell 1320 Cyan Std Cap
Dell 1320 Color Hi Cap	Dell 1320 Magenta Hi Cap
Dell 1320 Color Std Cap	Dell 1320 Megenta Std Cap
Dell 1320 Color Hi Cap	Dell 1320 Yellow Hi Cap
Dell 1320 Color Std Cap	Dell 1320 Yellow Std Cap
Dell 2130 Color Hi Cap	Dell 2130 Black Hi Cap
Dell 2130 Black Hi Cap	Dell 2130 Color Hi Cap
Dell 2130 Std Cap Black	Dell 2130 Std Cap Bk
Dell 2130 Std Cap Color	Dell 2130 Std Cap Color
Dell 2145	Dell 2145N / F916N Bk Std Cap
Dell 2145	Dell 2145N / F935N Y Hi Cap
Dell 2145	Dell 2145N / G534N C Std Cap
Dell 2145	Dell 2145N / G537N M Hi Cap
Dell 2145	Dell 2145N / H394N M Std Cap
Dell 2145	Dell 2145N / J390N Y Std Cap

Dell 2145	Dell 2145N / J394N C Hi Cap
Dell 2145	Dell 2145N / K442N Bk Hi Cap
Dell 3110	Dell 3110 Black / PF030 HC
Dell 3110	Dell 3110 Black Std Cap
Dell 3110	Dell 3110 Cyan / PF029 HC
Dell 3110	Dell 3110 Cyan Std Cap
Dell 3110	Dell 3110 Magenta / MW566 HC
Dell 3110	Dell 3110 Magenta Std Cap
Dell 3110	Dell 3110 Yellow / NF556 HC
Dell 3110	Dell 3110 Yellow Std Cap
Dell 3115	Dell 3115 Black Hi Cap
Dell 3115	Dell 3115 Cyan Hi Cap
Dell 3115	Dell 3115 Magents Hi Cap
Dell 3115	Dell 3115 Yellow Hi Cap
Dell 3130	Dell 3130 Black Hi Cap
Dell 3130	Dell 3130 Black Std Cap
Dell 3130	Dell 3130 Cyan Hi Cap
Dell 3130	Dell 3130 Cyan Std Cap
Dell 3130	Dell 3130 Magenta Hi Cap
Dell 3130	Dell 3130 Magenta Std Cap
Dell 3130	Dell 3130 Yellow Hi Cap
Dell 3130	Dell 3130 Yellow Std Cap
Dell 5100	Dell 5100 / GG577 / H5702 Black
Dell 5100	Dell 5100 / GG578 M
Dell 5100	Dell 5100 / GG579 C
Dell 5100	Dell 5100 / HG308 Y
Dell 5110	Dell 5110 / GD898 HC B
Dell 5110	Dell 5110 / GD900 HC C
Dell 5110	Dell 5110 / GD907 SC C
Dell 5110	Dell 5110 / GD908 SC Y
Dell 5110	Dell 5110 / JD746 SC B
Dell 5110	Dell 5110 / JD750 HC Y
Dell 5110	Dell 5110 / KD556 SC M
Dell 5110	Dell 5110 / KD557 HC M
Dell Drums Laser	
Dell 2230	Dell 2230 / 593-10338 Drum
Dell 2330d / 2330dn / 2350d /2350dn Drum	Dell 2330DN / PK496 Drum
Dell P1700 / 1700N / 1710 Drum	Dell P1700 / D4283 Drum
Dell P1700 / 1700N / 1710 Drum	Dell P1700 / W5389 Drum
Dell P1720 Drum	Dell P1720 / MW685 Drum
Dell P1720 Drum	Dell P1720 / TJ987 Drum
Epson Laser	
EPL-6200 / S050166	S050166
Epson C2800 / S051158 Hi Cap Y	S051158 Hi Cap Y
Epson C2800 / S051159 Hi Cap M	S051159 Hi Cap M
Epson C2800 / S051160 Hi Cap C	S051160 Hi Cap C
Epson C2800 / S051161 Hi Cap B	S051161 Hi Cap B
Epson C2800 / S051162 Std Cap Y	S051162 Std Cap Y
Epson C2800 / S051163 Std Cap M	S051163 Std Cap M
Epson C2800 / S051164 Std Cap C	S051164 Std Cap C
Epson C2800 / S051165 Std Cap B	S051165 Std Cap B
Epson EPL-6200 Toner	SO50167
Epson EPL-6200 Drum	SO51099
Fusers Laser	
All Brother Fusers	All Brother Fusers
All Canon Fusers	All Canon Fusers
All Dell Fusers	All Dell Fusers
All Epson Fusers	All Epson Fusers
All HP Fusers	All HP Fusers
All IBM Fusers	All IBM Fusers
All Konica Fusers	All Konica Fusers
All Kyocera Fusers	All Kyocera Fusers

All Lexmark Fusers	All Lexmark Fusers
All Oki Fusers	All Oki Fusers
All Panasonic Fusers	All Panasonic Fusers
All Samsung Fusers	All Samsung Fusers
HP Laser	
HP LaserJet P2035 / P2055 Black Toner	HP No 05X / CE505X HI CAP
HP LaserJet P2035 / P2055 Black Toner	HP No 05A / CE505A
HP 5L / 5ML / 6L / 6ML / 3100 / 3150	HP No 06A / C3906A
HP Series 5Si / 8000	HP No 09A / C3909A
HP Series 5Si / 8000	HP No 09X / C3909X
HP LaserJet 2300 / 2300N	HP No 10A / Q2610A
HP LaserJet 2410	HP No 11A / Q6511A
HP LaserJet 2410	HP No 11X / Q6511X
HP LaserJet 1010 / 12 / 15 / 18 / 20 / 22 / 32 / 3015 / 20 / 30	HP No 12A / Q2612A
HP 1300 / 1300A	HP No 13A / Q2613A
HP 1300 / 1300X	HP No 13X / Q2613X
HP LaserJet 1000 / 05 / 1200 / 20 / 3300 / 20 / 30 Std Cap	HP No 15A / C7115A
HP LaserJet 1000 / 05 / 1200 / 20 / 3300 / 20 / 30 High Cap	HP No 15X / C7115X
HP LaserJet 5200 Printer series	HP No 16A / Q7516A
HP 1150	HP No 24A / Q2624A
HP 4000 / 4000N / 4000T / 4050	HP No 27A / C4127A
HP 4000 / 4000N / 4000T / 4050	HP No 27X / C4127X
HP 5000 / 5100	HP No 29X / C4129X
HP LaserJet P1005 / P1006 Printers	HP No 35A / CB435A
HP LaserJet P1505 / P1505 Series	HP No 36A / CB436A
HP 4200	HP No 38A / Q1338A
HP 4300	HP No 39A / Q1339A
HP LaserJet 4240 / 4250 / 4350 Std Cap	HP No 42A / Q5942A
HP LaserJet 4240 / 4250 / 4350 High Cap	HP No 42X / Q5942X
HP 9000	HP No 43X / C8543X
HP 4345	HP No 45A / Q5945A
HP LaserJet 1160 / 1320 / 1320n / 1320nw / 1320tn	HP No 49A / Q5949A Std Cap
HP LaserJet 1160 / 1320 / 1320n / 1320nw / 1320tn	HP No 49X / Q5949X High Cap
HP LaserJet M3027 / 3035 / P3005 Std Cap	HP No 51A / Q7551A
HP LaserJet M3027 / 3035 / P3005 High Cap	HP No 51X / Q7551X
HP LaserJet P2015 Printers Series A	HP No 53A / Q7553A
HP LaserJet P2015 Printers Series X	HP No 53X / Q7553X
HP Laserjet Enterprise P3015	HP No 55A / CE255A Std Cap
HP Laserjet Enterprise P3015	HP No 55X / CE255X Hi Cap
HP 4100	HP No 61A / C8061A
HP 4100	HP No 61X / C8061X
HP LaserJet P4014 / P4050 / P4515 Series	HP No 64A / CC364A
HP LaserJet P4014 / P4050 / P4515 Series	HP No 64X / CC364X
HP LaserJet M5025 mfp / 5035	HP No 70A / Q7570A
HP LaserJet 4L / 4P / 4ML / 4MP	HP No 74A / 92274A
HP LaserJet Pro P1566	HP No 78A / CE278A
HP 8100 & 8150 & Mopier 320	HP No 82X / C4182X
HP CE285A	HP No 85A / CE285A
HP 1100 / 1100A / 3200	HP No 92A / C4092A
HP LaserJet 2100 series / 2200 series	HP No 96A / C4096A
HP LaserJet 4 / 4+ / 4M / 4M+ / 5 / 5N / 5M	HP No 98A / 92298A
HP LaserJet 4 / 4+ / 4M / 4M+ / 5 / 5N / 5M	HP No 98X / 92298X
HP Colors Laser	
HP Color LaserJet CP6015, CM6030, CM6040	HP CB380A Black
HP Color LaserJet CP6015, CM6030, CM6040	HP CB381A Cyan
HP Color LaserJet CP6015, CM6030, CM6040	HP CB382A Yellow
HP Color LaserJet CP6015, CM6030, CM6040	HP CB383A Magenta
HP Color LaserJet CM6030 F MFP/MFP/6040 F MFP/MFP	HP CB390A Black
HP Color LaserJet CP4005	HP CB400A Black
HP Color LaserJet CP4005	HP CB401A Colors
HP Color LaserJet CP4005	HP CB402A Colors
HP Color LaserJet CP4005	HP CB403A Colors

HP Color LaserJet CP1215 / CP1515	HP CB540A Black
HP Color LaserJet CP1215 / CP1515	HP CB541A Color
HP Color LaserJet CP1215 / CP1515	HP CB542A Color
HP Color LaserJet CP1215 / CP1515	HP CB543A Color
HP Color LaserJet CP2025/CM2320	HP CC530A Black
HP Color LaserJet CP2025/CM2320	HP CC531A Cyan
HP Color LaserJet CP2025/CM2320	HP CC532A Yellow
HP Color LaserJet CP2025/CM2320	HP CC533A Magenta
HP CM 3530 FS MFP/MFP/CP 3525/3525 DN/N/X	HP CE250A Black Std Cap
HP CM 3530 FS MFP/MFP/CP 3525/3525 DN/N/X	HP CE250X Black Hi Cap
HP CM 3530 FS MFP/MFP/CP 3525/3525 DN/N/X	HP CE251A
HP CM 3530 FS MFP/MFP/CP 3525/3525 DN/N/X	HP CE252A
HP CM 3530 FS MFP/MFP/CP 3525/3525 DN/N/X	HP CE253A
HP CE260A Black Std Cap	HP CE260A Black Std Cap
HP CE260X Black Hi Cap	HP CE260X Black Hi Cap
HP CE261A Cyan	HP CE261A Cyan
HP CE262A Yellow	HP CE262A Yellow
HP CE263A Magenta	HP CE263A Magenta
HP Color LaserJet CM4540	HP CE264X Black Hi Cap
HP Color LaserJet CP5525	HP CE270A Black
HP Color LaserJet CP5525	HP CE271A Cyan
HP Color LaserJet CP5525	HP CE272A Yellow
HP Color LaserJet CP5525	HP CE273A Magenta
HP Color LaserJet CP1020 / CP1025	HP CE310A / 126A Black
HP Color LaserJet CP1020 / CP1025	HP CE311A / 126A Cyan
HP Color LaserJet CP1020 / CP1025	HP CE312A / 126A Yellow
HP Color LaserJet CP1020 / CP1025	HP CE313A / 126A Magenta
HP Color LaserJet CP1415 / CP1525	HP CE320A / 128A Black
HP Color LaserJet CP1415 / CP1525	HP CE321A / 128A Cyan
HP Color LaserJet CP1415 / CP1525	HP CE322A / 128A Yellow
HP Color LaserJet CP1415 / CP1525	HP CE323A / 128A Magenta
HP CP5225 CE740	HP CE740
HP CP5225 CE741	HP CE741
HP CP5225 CE742	HP CE742
HP CP5225 CE743	HP CE743
HP Color LaserJet CM4540	HP CF031A Cyan
HP Color LaserJet CM4540	HP CF032A Yellow
HP Color LaserJet CM4540	HP CF033A Magenta
HP 3500 (black)	HP Q2670A
HP 3500 (Color)	HP Q2671A
HP 3500 (Color)	HP Q2672A
HP 3500 (Color)	HP Q2673A
HP 3500 (black)	HP Q2680A
HP 3700 (Color)	HP Q2681A
HP 3700 (Color)	HP Q2682A
HP 3700 (Color)	HP Q2683A
HP Color LaserJet 2550 (Black)	HP Q3960A
HP Color LaserJet 2550 (Black)	HP Q3961A
HP Color LaserJet 2550 (Color)	HP Q3962A
HP Color LaserJet 2550 (Color)	HP Q3963A
HP Color LaserJet 2550 (Color)	HP Q3970A
HP Color LaserJet 2550 (Color)	HP Q3971A
HP Color LaserJet 2550 (Color)	HP Q3972A
HP Color LaserJet 2550 (Color)	HP Q3973A
HP 4700 (black)	HP Q5950A
HP 4700 (Color)	HP Q5951A
HP 4700 (Color)	HP Q5952A
HP 4700 (Color)	HP Q5953A
HP Color LaserJet 2600 / 2605 / 1015 / 1018	HP Q6000A Black
HP Color LaserJet 2600 / 2605 / 1015 / 1018	HP Q6001A Color
HP Color LaserJet 2600 / 2605 / 1015 / 1019	HP Q6002A Color
HP Color LaserJet 2600 / 2605 / 1015 / 1020	HP Q6003A Color

HP 4730 (black)	HP Q6460A
HP 4730 (Color)	HP Q6461A
HP 4730 (Color)	HP Q6462A
HP 4730 (Color)	HP Q6463A
HP 3600 / 3800 (black)	HP Q6470A
HP 3600 (Color)	HP Q6471A
HP 3600 (Color)	HP Q6472A
HP 3600 (Color)	HP Q6473A
HP 2700 / 3000 (black)	HP Q7560A
HP 2700 / 3000 (Color)	HP Q7561A
HP 2700 / 3000 (Color)	HP Q7562A
HP 2700 / 3000 (Color)	HP Q7563A
HP 3800 (Color)	HP Q7581A
HP 3800 (Color)	HP Q7582A
HP 3800 (Color)	HP Q7883A
HP Drums Laser	
HP 1500 / 2500 Drum	HP C9704A Drum
HP Color LaserJet CP6015, CM6030, CM6040	HP CB384A Black Drum
HP Color LaserJet CP6015, CM6030, CM6040	HP CB385A Cyan Drum
HP Color LaserJet CP6015, CM6030, CM6040	HP CB386A Yellow Drum
HP Color LaserJet CP6015, CM6030, CM6040	HP CB387A Magenta Drum
HP Color LaserJet CP5525	HP CE314A Drum
HP Color LaserJet 2550 / 2550L / 2550N / 2550LN	HP Q3964A Drum
HP Intro Laser	
HP Color LaserJet CP1215 / CP1516	HP CB540A Black (INTRO)
HP Color LaserJet CP1215 / CP1515	HP CB541A Color (INTRO)
HP Color LaserJet CP1215 / CP1515	HP CB542A Color (INTRO)
HP Color LaserJet CP1215 / CP1515	HP CB543A Color (INTRO)
HP Color LaserJet CP2025/CM2320	HP CC530A Black (INTRO)
HP Color LaserJet CP2025/CM2320	HP CC531A Color (INTRO)
HP Color LaserJet CP2025/CM2320	HP CC532A Color (INTRO)
HP Color LaserJet CP2025/CM2320	HP CC533A Color (INTRO)
HP CM 3530 FS MFP/MFP/CP 3525/3525 DN/N/X	HP CE250A Black Std Cap (INTRO)
HP CM 3530 FS MFP/MFP/CP 3525/3525 DN/N/X	HP CE251A (INTRO)
HP CM 3530 FS MFP/MFP/CP 3525/3525 DN/N/X	HP CE252A (INTRO)
HP CM 3530 FS MFP/MFP/CP 3525/3525 DN/N/X	HP CE253A (INTRO)
HP CE260A Black (INTRO)	HP CE260A Black (INTRO)
HP CE261A Cyan (INTRO)	HP CE261A Cyan (INTRO)
HP CE262A Yellow (INTRO)	HP CE262A Yellow (INTRO)
HP CE263A Magenta (INTRO)	HP CE263A Magenta (INTRO)
HP Color LaserJet CP1415 / CP1525	HP CE320A / 128A Black INTRO
HP Color LaserJet CP1415 / CP1525	HP CE321A / 128A Cyan INTRO
HP Color LaserJet CP1415 / CP1525	HP CE322A / 128A Yellow INTRO
HP Color LaserJet CP1415 / CP1525	HP CE323A / 128A Magenta INTRO
HP CP5225 CE741 (INTRO)	HP CE741 (INTRO)
HP CP5225 CE742 (INTRO)	HP CE742 (INTRO)
HP CP5225 CE743 (INTRO)	HP CE743 (INTRO)
HP Color LaserJet CM4540	HP CF031A Cyan INTRO
HP Color LaserJet CM4540	HP CF032A Yellow INTRO
HP Color LaserJet CM4540	HP CF033A Magenta INTRO
HP LaserJet P1005 / P1006 Printers	HP No 35A / CB435A (INTRO)
HP LaserJet P1505 / P1505 Series	HP No 36A / CB436A (INTRO)
HP LaserJet P4014 / P4050 / P4515 Series	HP No 64A / CC364A (INTRO)
HP LaserJet Pro P1566	HP No 78A / CE278A (INTRO)
HP CE285A INTRO	HP No 85A / CE285A (INTRO)
IBM Laser	
IBM Infoprint 12 Series	01P6897
IBM Infoprint 1145 Series	28P1882
IBM Infoprint 1130 / 1140	28P2007
IBM Infoprint 1130 / 1140	28P2008 MICR
IBM Infoprint 1130 / 1140	28P2009 Std Cap
IBM Infoprint 1130 / 1140	28P2010 Hi Cap

IBM Infoprint 1116	28P2420
IBM Infoprint 1120 / 1125	28P2491
IBM Infoprint 1120 / 1125	28P2492 Hi Cap
IBM Infoprint 1120 / 1125	28P2493
IBM Infoprint 1120 / 1125	28P2494 Hi Cap
IBM Infoprint 21	38L1410
IBM Infoprint 1222	53P7704
IBM Infoprint 1222	53P7705
IBM Infoprint 1222	53P7706
IBM Infoprint 1222	53P7707
IBM Infoprint 4317 / Lexmark 4317 Network	63H2401
IBM Infoprint 1332 / 1352 / 1372	75P4300 Hi Cap
IBM Infoprint 1332 / 1352 / 1372	75P4301 Std Std
IBM Infoprint 1332 / 1352 / 1372	75P4302 Hi Cap
IBM Infoprint 1332 / 1352 / 1372	75P4303 Hi Cap
IBM Infoprint 1352 / 1372	75P4304 Extra Hi Cap
IBM Infoprint 1352 / 1372	75P4305 Extra Hi Cap
IBM Infoprint 1415 / 1515	75P5708
IBM Infoprint 1415 / 1514	75P5709
IBM Infoprint 1415 / 1513	75P5710 Hi Cap
IBM Infoprint 1415 / 1512	75P5711 Hi Cap
IBM Infoprint 1415 / 1516	75P5712 Drum
IBM Infoprint 1422	75P6049
IBM Infoprint 1422	75P6050
IBM Infoprint 1422	75P6051
IBM Infoprint 1422	75P6052
IBM Infoprint 1532 / 1552 / 1572 MFP Std Yield	75P6958
IBM Infoprint 1532 / 1552 / 1572 MFP Std Yield	75P6959
IBM Infoprint 1532 / 1552 / 1572 MFP High Yield	75P6960
IBM Infoprint 1532 / 1552 / 1572 MFP High Yield	75P6961
IBM Infoprint 1532 / 1552 / 1572 MFP Extra High Yield	75P6962
IBM Infoprint 1572 MFP Extra High Yield	75P6963
IBM Infoprint 20 / M5893GA	90H0748
Konica Laser	
MagiColor 2300 (Black) ** (Must have Plastic cover)	1710517-005 Black
MagiColor 2300 (Color) ** (Must have Plastic cover)	1710517-006 Yellow
MagiColor 2300 (Color) ** (Must have Plastic cover)	1710517-007 Magenta
MagiColor 2300 (Color) ** (Must have Plastic cover)	1710517-008 Cyan
MagiColor 5430 / 5430DL	1710582-001 Black Hi Cap
MagiColor 5430 / 5430DL	1710582-002 Yellow Hi Cap
MagiColor 5430 / 5430DL	1710582-003 Magenta Hi Cap
MagiColor 5430 / 5430DL	1710582-004 Cyan Hi Cap
MagiColor 2400 (Black) ** (Must have Plastic cover)	1710587-004 Black
MagiColor 2400 (Color) ** (Must have Plastic cover)	1710587-005 Yellow
MagiColor 2400 (Color) ** (Must have Plastic cover)	1710587-006 Magenta
MagiColor 2400 (Color) ** (Must have Plastic cover)	1710587-007 Cyan
Konica Minolta MF1600 / MF2600 / MF3600	4152-613 / TC-16
MagiColor 4650DN / 4650EN / 4690MF / 4695MF / 5670EN	A0DK151 Black
MagiColor 4650DN / 4650EN / 4690MF / 4695MF / 5670EN	A0DK152 Black Hi Cap
MagiColor 4650DN / 4650EN / 4690MF / 4695MF / 5670EN	A0DK251 Yellow
MagiColor 4650DN / 4650EN / 4690MF / 4695MF / 5670EN	A0DK252 Yellow Hi Cap
MagiColor 4650DN / 4650EN / 4690MF / 4695MF / 5670EN	A0DK351 Magenta
MagiColor 4650DN / 4650EN / 4690MF / 4695MF / 5670EN	A0DK352 Magenta Hi Cap
MagiColor 4650DN / 4650EN / 4690MF / 4695MF / 5670EN	A0DK451 Cyan
MagiColor 4650DN / 4650EN / 4690MF / 4695MF / 5670EN	A0DK452 Cyan Hi Cap
MagiColor 1600W / 1650EN / 1680MF / 1690MF	A0V301H Black Hi Cap
MagiColor 1600W / 1650EN / 1680MF / 1690MF	A0V305H Std Cap Yellow
MagiColor 1600W / 1650EN / 1680MF / 1690MF	A0V306H Hi Cap Yellow
MagiColor 1600W / 1650EN / 1680MF / 1690MF	A0V30AH Std Cap Magenta
MagiColor 1600W / 1650EN / 1680MF / 1690MF	A0V30CH Hi Cap Magenta
MagiColor 1600W / 1650EN / 1680MF / 1690MF	A0V30GH Std Cap Cyan
MagiColor 1600W / 1650EN / 1680MF / 1690MF	A0V30HH Hi Cap Cyan

MagiColor 1600W / 1650EN / 1680MF / 1690MF	A0VU0Y1 Drum
Lexmark Laser	
Lexmark E320 / E322	Lexmark 08A0475
Lexmark E320 / E322	Lexmark 08A0476
Lexmark E320 / E322	Lexmark 08A0477
Lexmark E320 / E322	Lexmark 08A0478
Lexmark E210	Lexmark 10S0150
Lexmark E120	Lexmark 12016SE
Lexmark E120	Lexmark 12036SE
Lexmark Optra S (Prebate)	Lexmark 12A0150 Hi Cap
Lexmark Optra SE	Lexmark 12A0725
Lexmark Optra SE	Lexmark 12A0825
Lexmark Optra SE	Lexmark 12A0829
Lexmark E310 / E312 / E312L 3k	Lexmark 12A2202
Lexmark E320 / E322	Lexmark 12A2260
Lexmark T520 / T522	Lexmark 12A3160 High Cap
Lexmark X422 MFP	Lexmark 12A3710
Lexmark X422 MFP	Lexmark 12A3715
Lexmark X422	Lexmark 12A4715
Lexmark T610, T612, T614, T616	Lexmark 12A5140 HI Cap
Lexmark T610, T612, T614, T616	Lexmark 12A5740
Lexmark T610, T612, T614, T616	Lexmark 12A5745
Lexmark T610, T612, T614, T616	Lexmark 12A5840
Lexmark T610 / T614	Lexmark 12A5845
Lexmark T610, T612, T614, T616	Lexmark 12A5849
Lexmark T620 / 12A6160 HC	Lexmark 12A6160 Hi Cap
Lexmark T520 / T522 / X520 / X522 / 12A6730	Lexmark 12A6730
Lexmark T520, T522, X520, X522	Lexmark 12A6735
Lexmark T520 / T522 / X520 / X524 / 12A6760	Lexmark 12A6760
Lexmark T620 / T622 / X620e / 12A6765	Lexmark 12A6765
Lexmark T520 / T522 / X520 / X523 / 12A6830	Lexmark 12A6830
Lexmark T520, T522, X520, X522 High Yield	Lexmark 12A6835 Hi Cap
Lexmark T520, T522, X520, X522	Lexmark 12A6839 Hi Cap
Lexmark T610 / T612 / T614 / T616	Lexmark 12A6844
Lexmark T620 / T622 / X620e / 12A6860	Lexmark 12A6860
Lexmark T620 / T622 / X620e	Lexmark 12A6865
Lexmark T620 / T622 / X620e / 12A6869	Lexmark 12A6869
Lexmark E321 / E323	Lexmark 12A7300
Lexmark E321 / E323 / 12A7305	Lexmark 12A7305
Lexmark T420	Lexmark 12A7310
Lexmark T420	Lexmark 12A7315
Lexmark T630 / T632 / T634 / X634 / X630 / X632	Lexmark 12A7360
Lexmark T630 / T632 / T634 / X634 / X630 / X633	Lexmark 12A7362
Lexmark T632 / T634 / X632 / 12A7365	Lexmark 12A7365
Lexmark E321 / E323 / 12A7400	Lexmark 12A7400
Lexmark E321 / E323	Lexmark 12A7405
Lexmark T420 / X422	Lexmark 12A7410
Lexmark X422	Lexmark 12A7415
Lexmark X632s	Lexmark 12A7460
Lexmark T630 / T632 / T634 / X630e / X632	Lexmark 12A7462
Lexmark T632 / T634 / X632	Lexmark 12A7465 Ex Hi Cap
Lexmark T632 / T634	Lexmark 12A7610 Ex Hi Cap
Lexmark T630 / T632 / T634	Lexmark 12A7612
Lexmark T620 / T622 / X620	Lexmark 12A7644
Lexmark T632 / T634	Lexmark 12A8044
Lexmark T630 / T632 / T634	Lexmark 12A8244
Lexmark E230 / E232 / E330 / E332 / E340 / E342 + Others	Lexmark 12A8300
Lexmark E230 / E232 / E330 / E332 / E340 / E342 + Others	Lexmark 12A8305
Lexmark T430	Lexmark 12A8320
Lexmark T430 / 12A8325	Lexmark 12A8325
Lexmark E230 / E232 / E330 / E332 / 12A8400	Lexmark 12A8400
Lexmark E230 / E232 / E330 / E332 / 12A8405	Lexmark 12A8405

Lexmark T430	Lexmark 12A8420
Lexmark T430 / 12A8425	Lexmark 12A8425
Lexmark T420 / 12A8544	Lexmark 12A8544
Lexmark W820	Lexmark 12B0090
Lexmark E220	Lexmark 12S0300
Lexmark E220	Lexmark 12S0400
Lexmark 4039	Lexmark 1380850
Lexmark 4039	Lexmark 1380950 Hi Cap
Lexmark 4049	Lexmark 1382100
Lexmark 4049	Lexmark 1382150 Hi Cap
Lexmark Optra S (Prebate)	Lexmark 1382620
Lexmark Optra S (Prebate)	Lexmark 1382625
Lexmark Optra S (Non Prebate)	Lexmark 1382920
Lexmark Optra S (Non Prebate)	Lexmark 1382925
Lexmark E310 / E312 / E312L 6k	Lexmark 13T0101
Lexmark E310 / E312 / E312L	Lexmark 13T0301
Lexmark Optra M / M410 / M412	Lexmark 17G0152 Low Vol
Lexmark Optra M / M410 / M412	Lexmark 17G0154 Hi Cap
Lexmark X215	Lexmark 18S0090
Lexmark Optra M / M410 / M412	Lexmark 4K00199 Std Cap
Lexmark T640 / T642 / T644 / High Yield	Lexmark 64004HE Hi Cap
Lexmark T640 / T642 / T644	Lexmark 64015HA
Lexmark T640 / T642 / T644	Lexmark 64016HE
Lexmark T640 / T642 / T644 / Std Yield	Lexmark 64016SE
Lexmark T640 / T642 / T644 / High Yield	Lexmark 64036HE
Lexmark T640 / T642 / T644 / Std Yield	Lexmark 64036SE
Lexmark T640 / T642 / T644 / 64040HW High Cap	Lexmark 64040HW High Cap
Lexmark T640/T642/T644/X640E/X642E/X644E/X646E	Lexmark 64080HW Hi Cap
Lexmark T644 / 64416XE	Lexmark 64416XE
Lexmark T644 Extra High Yield	Lexmark 64436XE
Lexmark T644	Lexmark 64440XW Ex Hi Cap
Lexmark Optra E (Toner)	Lexmark 69G8256
Lexmark E230 / E232 / E240 / E330 / E332 / E340 / E342n	Lexmark E24016SE
Lexmark E230 / E232 / E240 / E330 / E332 / E340 / E342n	Lexmark E24036SE
Lexmark E250 / 350 / 352 / 450	Lexmark E250A11E
Lexmark E250 / 350 / 352 / 450	Lexmark E250A21E
Lexmark E260	Lexmark E260A11E
Lexmark E260/360/460 Standard Toner	Lexmark E260A21E
Lexmark E340	Lexmark E34016HE
Lexmark E340/342/232/330/332 Toner	Lexmark E34036HE
Lexmark E340 / E340A11G	Lexmark E340A11G
Lexmark X340 / E342e Toner	Lexmark E340A21G
Lexmark E352	Lexmark E352H11E
Lexmark E350 / E352	Lexmark E352H31E
Lexmark E350/352 Toner	Lexmark E353H21E
Lexmark E360	Lexmark E360H11E
Lexmark E360 / 460 High Yield Toner	Lexmark E360H21E
Lexmark E450	Lexmark E450A11E
Lexmark E450	Lexmark E450A21E
Lexmark E450	Lexmark E450H11E
Lexmark E450	Lexmark E450H21E
Lexmark E460	Lexmark E460X11E
Lexmark E460 Extra High Yield Toner	Lexmark E460X21E
Lexmark E460	Lexmark E460X31E
Lexmark T650 / T650A11E	Lexmark T650A11E
Lexmark T650 / 652 / 654 Standard Yield	Lexmark T650A21E
Lexmark T650 / T650H11E	Lexmark T650H11E
Lexmark T650 / 652 / 654 High Yield	Lexmark T650H21E
Lexmark T650 / T652 / T654	Lexmark T650H31E HC
Lexmark T654 / T654X11A	Lexmark T654X11A
Lexmark T654 Extra High Yield	Lexmark T654X21A
Lexmark T654 Extra High Yield	Lexmark T654X31E

Lexmark X264dn / X363dn / X364dn / X364dw	Lexmark X264A11G SC
Lexmark X264dn / X363dn / X364dn / X364dw	Lexmark X264A21G SC
Lexmark X264dn / X363dn / X364dn / X364dw	Lexmark X264H11G HC
Lexmark X264dn / X363dn / X364dn / X364dw	Lexmark X264H21G HC
Lexmark X340 / X340A21G	Lexmark X340A21G
Lexmark X340	Lexmark X340H11G
Lexmark X340	Lexmark X340H22G
Lexmark X463 / X463H11G	Lexmark X463H11G
Lexmark X463 / X463X11G	Lexmark X463X11G
Lexmark X463 / X463X31G	Lexmark X463X31G
Lexmark X644 / X644A11E	Lexmark X644A11E
Lexmark X644 Extra High Yield	Lexmark X644A21E
Lexmark X644 Extra High Yield	Lexmark X644A31E (GERMANY)
Lexmark X644 / X644H11E	Lexmark X644H11E
Lexmark X642e / X644 High Yield	Lexmark X644H21E
Lexmark X644 / X644X11E	Lexmark X644X11E
Lexmark X642e / X644 Standard Yield	Lexmark X644X21E
Lexmark X651 / X651A11E	Lexmark X651A11E
Lexmark X651/652/654/656/658 High Yield	Lexmark X651A21E
Lexmark X651 / X651H11E	Lexmark X651H11E
Lexmark X651/652/654/656/658 High Yield	Lexmark X651H21E
Lexmark X654 / X654X11E	Lexmark X654X11E
Lexmark X654 / 656 / 658 Extra High Yield	Lexmark X654X21E
Lexmark X830e / X832e	Lexmark X8302KH
Lexmark X850 / 852 / 854	Lexmark X850H21G
Lexmark Colors Laser	
Lexmark C910 / C910N / C912 / X912E	Lexmark 12N0768 C
Lexmark C910 / C910N / C912 / X912E	Lexmark 12N0769 M
Lexmark C910 / C910N / C912 / X912E	Lexmark 12N0770 Y
Lexmark C910 / C910N / C912 / X912E	Lexmark 12N0771 B
Lexmark SC 1275	Lexmark 1361751
Lexmark SC 1275	Lexmark 1361752
Lexmark SC 1275	Lexmark 1361753
Lexmark SC 1275	Lexmark 1361754
Lexmark C752	Lexmark 15G041C LOW CAP C
Lexmark C752	Lexmark 15G041K LOW CAP B
Lexmark C752	Lexmark 15G041M LOW CAP M
Lexmark C752	Lexmark 15G041Y LOW CAP Y
Lexmark C752	Lexmark 15G042C HI CAP C
Lexmark C752	Lexmark 15G042K HI CAP B
Lexmark C752	Lexmark 15G042M HI CAP M
Lexmark C752	Lexmark 15G042Y HI CAP Y
Lexmark C720	Lexmark 15W0900
Lexmark C720	Lexmark 15W0901
Lexmark C720	Lexmark 15W0902
Lexmark C720	Lexmark 15W0903
Lexmark C510 / C510N Black	Lexmark 20K0500
Lexmark C510 / C510N Color	Lexmark 20K0501
Lexmark C510 / C510N Color	Lexmark 20K0502
Lexmark C510 / C510N Color	Lexmark 20K0503
Lexmark C510 / C510N Black Hi Cap	Lexmark 20K1400 Hi Cap
Lexmark C510 / C510N Color Hi Cap	Lexmark 20K1401 Hi Cap
Lexmark C510 / C510N Color Hi Cap	Lexmark 20K1402 Hi Cap
Lexmark C510 / C510N Color Hi Cap	Lexmark 20K1403 Hi Cap
Lexmark C500 / X500N / X502N	Lexmark C500H2CG Hi Cap
Lexmark C500 / X500N / X502N	Lexmark C500H2KG Hi Cap
Lexmark C500 / X500N / X502N	Lexmark C500H2MG Hi Cap
Lexmark C500 / X500N / X502N	Lexmark C500H2YG Hi Cap
Lexmark C500 / X500N / X502N	Lexmark C500S2CG Std Cap
Lexmark C500 / X500N / X502N	Lexmark C500S2KG Std Cap
Lexmark C500 / X500N / X502N	Lexmark C500S2MG Std Cap
Lexmark C500 / X500N / X502N	Lexmark C500S2YG Std Cap

Lexmark C522 / C524 / C530DN / C532DN / C534x	Lexmark C5220CS Std Cap
Lexmark C522 / C524 / C530DN / C532DN / C534x	Lexmark C5220KS Std Cap
Lexmark C522 / C524 / C530DN / C532DN / C534x	Lexmark C5220MS Std Cap
Lexmark C522 / C524 / C530DN / C532DN / C534x	Lexmark C5220YS Std Cap
Lexmark C522 / C524 / C530DN / C532DN / C534x	Lexmark C5222CS Std Cap
Lexmark C522 / C524 / C530DN / C532DN / C534x	Lexmark C5222KS Std Cap
Lexmark C522 / C524 / C530DN / C532DN / C534x	Lexmark C5222MS Std Cap
Lexmark C522 / C524 / C530DN / C532DN / C534x	Lexmark C5222YS Std Cap
Lexmark C524 / C532DN / C534x	Lexmark C5240CH Hi Cap
Lexmark C524 / C532DN / C534x	Lexmark C5240KH Hi Cap
Lexmark C524 / C532DN / C534x	Lexmark C5240MH HC M
Lexmark C524 / C532DN / C534x	Lexmark C5240YH Hi Cap
Lexmark C524 / C532DN / C534x	Lexmark C5242CH Hi Cap
Lexmark C524 / C532DN / C534x	Lexmark C5242KH Hi Cap
Lexmark C524 / C532DN / C534x	Lexmark C5242MH Hi Cap
Lexmark C524 / C532DN / C534x	Lexmark C5242YH Hi Cap
Lexmark C540 / C543 / C544 / C546 / X543 / X544 / X546	Lexmark C540A1CG SC C
Lexmark C540 / C543 / C544 / C546 / X543 / X544 / X546	Lexmark C540A1KG SC B
Lexmark C540 / C543 / C544 / C546 / X543 / X544 / X546	Lexmark C540A1MG SC M
Lexmark C540 / C543 / C544 / C546 / X543 / X544 / X546	Lexmark C540A1YG SC Y
Lexmark C540 / C543 / C544 / C546 / X543 / X544 / X546	Lexmark C540H1CG HC C
Lexmark C540 / C543 / C544 / C546 / X543 / X544 / X546	Lexmark C540H1KG HC B
Lexmark C540 / C543 / C544 / C546 / X543 / X544 / X546	Lexmark C540H1MG HC M
Lexmark C540 / C543 / C544 / C546 / X543 / X544 / X546	Lexmark C540H1YG HC Y
Lexmark C540 / C543 / C544 / C546 / X543 / X544 / X546	Lexmark C540H2CG HC C
Lexmark C540 / C543 / C544 / C546 / X543 / X544 / X546	Lexmark C540H2KG HC B
Lexmark C540 / C543 / C544 / C546 / X543 / X544 / X546	Lexmark C540H2MG HC M
Lexmark C540 / C543 / C544 / C546 / X543 / X544 / X546	Lexmark C540H2YG HC Y
Lexmark C734 / C736 / X734 / X736 / X738n	Lexmark C734A1CG Cyan
Lexmark C734 / C736 / X734 / X736 / X738n	Lexmark C734A1KG Black
Lexmark C734 / C736 / X734 / X736 / X738n	Lexmark C734A1MG Magenta
Lexmark C734 / C736 / X734 / X736 / X738n	Lexmark C734A1YG Yellow
Lexmark C734 / C736 / X734 / X736 / X738n	Lexmark C734A2CG Cyan
Lexmark C734 / C736 / X734 / X736 / X738n	Lexmark C734A2KG Black
Lexmark C734 / C736 / X734 / X736 / X738n	Lexmark C734A2MG Magenta
Lexmark C734 / C736 / X734 / X736 / X738n	Lexmark C734A2YG Yellow
Lexmark C770DN / C770DTN / C770N / C770X / C772X	Lexmark C7700CS Std Cap
Lexmark C770DN / C770DTN / C770N / C770X / C772X	Lexmark C7700KS Std Cap
Lexmark C770DN / C770DTN / C770N / C770X / C772X	Lexmark C7700MS Std Cap
Lexmark C770DN / C770DTN / C770N / C770X / C772X	Lexmark C7700YS Std Cap
Lexmark C772DN / C772DTN / C772N	Lexmark C7720CX Hi Cap
Lexmark C772DN / C772DTN / C772N	Lexmark C7720KX Hi Cap
Lexmark C772DN / C772DTN / C772N	Lexmark C7720MKX Hi Cap
Lexmark C772DN / C772DTN / C772N	Lexmark C7720YX Hi Cap
Lexmark C780x / C782n / C782x	Lexmark C780A1CG LOW CAP C
Lexmark C780x / C782n / C782x	Lexmark C780A1KG LOW CAP B
Lexmark C780x / C782n / C782x	Lexmark C780A1MG LOW CAP M
Lexmark C780x / C782n / C782x	Lexmark C780A1YG LOW CAP Y
Lexmark C780x / C782n / C782x	Lexmark C780H1CG HI CAP C
Lexmark C780x / C782n / C782x	Lexmark C780H1KG HI CAP B
Lexmark C780x / C782n / C782x	Lexmark C780H1MG HI CAP M
Lexmark C780x / C782n / C782x	Lexmark C780H1YG HI CAP Y
Lexmark C920 / C920DN / C920DTN / C920N	Lexmark C9202CH C
Lexmark C920 / C920DN / C920DTN / C920N	Lexmark C9202KH B
Lexmark C920 / C920DN / C920DTN / C920N	Lexmark C9202MH M
Lexmark C920 / C920DN / C920DTN / C920N	Lexmark C9202YH Y
Lexmark C930 / C930DN / C930DTN / C930N	Lexmark C930H2CG Cyan
Lexmark C930 / C930DN / C930DTN / C930N	Lexmark C930H2KG Black
Lexmark C930 / C930DN / C930DTN / C930N	Lexmark C930H2MG Megenta
Lexmark C930 / C930DN / C930DTN / C930N	Lexmark C930H2YG Yellow
Lexmark Drum Laser	
Lexmark E120	Lexmark 12026XW Drum

Lexmark E230 / E232 / E330 / E332 / E340 / E342 Drum	Lexmark 12A8302 Drum
Lexmark C540 / C543 / C544 / C546 / X543 / X544 / X546	Lexmark C540X32G Cyan Drum
Lexmark C540 / C543 / C544 / C546 / X543 / X544 / X546	Lexmark C540X33G Magenta Drum
Lexmark C540 / C543 / C544 / C546 / X543 / X544 / X546	Lexmark C540X34G Yellow Drum
Lexmark C540 / C543 / C544 / C546 / X543 / X544 / X546	Lexmark C540X35G Black Drum
Lexmark E250 / 350 / 352 / 450	Lexmark E250X22G Drum
Lexmark E260/360/460 Drum	Lexmark E260X22G Drum
Lexmark X850 / 852 / 854 Drum	Lexmark X850H22G Drum
OKI Laser	
OkI 3300 43459329 Y HI Cap	Type 3300 43459329 Yellow HI Cap
OkI 3300 43459330 M HI Cap	Type 3300 43459330 Magenta HI Cap
OkI 3300 43459331 C HI Cap	Type 3300 43459331 Cyan HI Cap
OkI 3300 43459332 B HI Cap	Type 3300 43459332 Black HI Cap
OkI 3300 43459433 Y Std Cap	Type 3300 43459433 Yellow Std Cap
OkI 3300 43459434 M Std Cap	Type 3300 43459434 Magenta Std Cap
OkI 3300 43459435 C Std Cap	Type 3300 43459435 Cyan Std Cap
OkI 3300 43459436 B Std Cap	Type 3300 43459436 Black Std Cap
OkI C7100 / C7300 / C7350 / C7500	Type 41963005 Yellow
OkI C7100 / C7300 / C7350 / C7500	Type 41963006 Magenta
OkI C7100 / C7300 / C7350 / C7500	Type 41963007 Cyan
OkI C7100 / C7300 / C7350 / C7500	Type 41963008 Black
OkI B430/440/460/470/480 SC	Type 43979102
OkI B430/440/460/470/480 HI	Type 43979202
OKI C5600 / 5700	Type 5600 / 5700 Black
OKI C5600 / 5700	Type 5600 / 5700 Cyan
OKI C5600 / 5700	Type 5600 / 5700 Magenta
OKI C5600 / 5700	Type 5600 / 5700 Yellow
OkI B4200	Type B4200 / 1103402
OkI C110 / C130n Hi Cap B	Type C110 / C130n Hi Cap Black
OkI C110 / C130n Hi Cap C	Type C110 / C130n Hi Cap Cyan
OkI C110 / C130n Hi Cap M	Type C110 / C130n Hi Cap Magenta
OkI C110 / C130n Hi Cap Y	Type C110 / C130n Hi Cap Yellow
OkI C110 / C130n Std Cap B	Type C110 / C130n Std Cap Black
OkI C110 / C130n Std Cap C	Type C110 / C130n Std Cap Cyan
OkI C110 / C130n Std Cap M	Type C110 / C130n Std Cap Magenta
OkI C110 / C130n Std Cap Y	Type C110 / C130n Std Cap Yellow
OKI C7000 / C7200	Type C2 41304209 Yellow
OKI C7000 / C7200	Type C2 41304210 Magenta
OKI C7000 / C7200	Type C2 41304211 Cyan
OKI C7000 / C7200	Type C2 41304212 Black
OKI C5 9300 / 9500	Type C5 9300 / 9500 Black
OKI C5 9300 / 9500	Type C5 9300 / 9500 Cyan
OKI C5 9300 / 9500	Type C5 9300 / 9500 Magenta
OKI C5 9300 / 9500	Type C5 9300 / 9500 Yellow
OKI Type C6 50/51/52/53/5400	Type C6 50/51/52/53/5400 Black
OkI Type C6 50/51/52/53/5400 B Drum	Type C6 50/51/52/53/5400 Black Drum
OKI Type C6 50/51/52/53/5400	Type C6 50/51/52/53/5400 Cyan
OKI Type C6 50/51/52/53/5400	Type C6 50/51/52/53/5400 Magenta
OKI Type C6 50/51/52/53/5400	Type C6 50/51/52/53/5400 Yellow
OKI 3100 Series all Colors	Type C6L 3100 Series all Colors NOT INTRO
OKI C7 9600/C9650/C9800/C9850	Type C7 9600 / 9800 Black
OKI C7 9600/C9650/C9800/C9850	Type C7 9600 / 9800 Cyan
OKI C7 9600/C9650/C9800/C9850	Type C7 9600 / 9800 Magenta
OKI C7 9600/C9650/C9800/C9850	Type C7 9600 / 9800 Yellow
OkI C710 / C711 Black	Type C710 / C711 Black
OkI C710 / C711 Cyan	Type C710 / C711 Cyan
OkI C710 / C711 Magenta	Type C710 / C711 Magenta
OkI C710 / C711 Yellow	Type C710 / C711 Yellow
OKI C8600 / 8800	Type C8600 / 8800 Cyan 43487711
OKI C8600 / 8800	Type C8600 / 8800 Magenta 43487710
OKI C8600 / 8800	Type C8600 / 8800 Yellow 43487709
OkI C9200 / C9400 Black	Type C9200 / C9400 Black

Okii C9200 / C9400 Cyan	Type C9200 / C9400 Cyan
Okii C9200 / C9400 Magents	Type C9200 / C9400 Magents
Okii C9200 / C9400 Yellow	Type C9200 / C9400 Yellow
OKI Drum Laser	
OKI Page 400e/410ex/600ex/800e Drum Unit	Page 400e/410ex/600ex/800e Drum Unit
Okii C7100 / C7300 / C7350 / C7500	Type 41962808 Black Drum
Okii C7100 / C7300 / C7350 / C7500	Type 41962808 Cyan Drum
Okii C7100 / C7300 / C7350 / C7500	Type 41962808 Magenta Drum
Okii C7100 / C7300 / C7350 / C7500	Type 41962808 Yellow Drum
OKI C5600 / 5700	Type 5600 / 5700 Black Drum
OKI C5600 / 5700	Type 5600 / 5700 Cyan Drum
OKI C5600 / 5700	Type 5600 / 5700 Magenta Drum
OKI C5600 / 5700	Type 5600 / 5700 Yellow Drum
Okii B4200 Drum	Type B4200 / 42102802
OKI C7000 / C7200	Type C2 41304109 Yellow Drum
OKI C7000 / C7200	Type C2 41304110 Magenta Drum
OKI C7000 / C7200	Type C2 41304111 Cyan Drum
OKI C7000 / C7200	Type C2 41304112 Black Drum
OKI C5 9300 / 9500 Drum	Type C5 9300 / 9500 Black Drum
OKI C5 9300 / 9500 Drum	Type C5 9300 / 9500 Cyan Drum
OKI C5 9300 / 9500 Drum	Type C5 9300 / 9500 Magenta Drum
OKI C5 9300 / 9500 Drum	Type C5 9300 / 9500 Yellow Drum
Okii Type C6 50/51/52/53/5400 C Drum	Type C6 50/51/52/53/5400 Cyan Drum
Okii Type C6 50/51/52/53/5400 M Drum	Type C6 50/51/52/53/5400 Magenta Drum
Okii Type C6 50/51/52/53/5400 Y Drum	Type C6 50/51/52/53/5400 Yellow Drum
OKI C7 9600/C9650/C9800/C9850 Drum	Type C7 9600 / 9800 Black Drum
OKI C7 9600/C9650/C9800/C9850 Drum	Type C7 9600 / 9800 Cyan Drum
OKI C7 9600/C9650/C9800/C9850 Drum	Type C7 9600 / 9800 Magenta Drum
OKI C7 9600/C9650/C9800/C9850 Drum	Type C7 9600 / 9800 Yellow Drum
OKI C8600 / 8800 Drum	Type C8600 / 8800 Black Drum 43449016
OKI C8600 / 8800 Drum	Type C8600 / 8800 Cyan Drum 43449015
OKI C8600 / 8800 Drum	Type C8600 / 8800 Magenta Drum 43449014
OKI C8600 / 8800 Drum	Type C8600 / 8800 Yellow Drum 43449013
Okii C9200 / C9400 Black Drum	Type C9200 / C9400 Black Drum
Okii C9200 / C9400 Cyan Drum	Type C9200 / C9400 Cyan Drum
Okii C9200 / C9400 Magenta Drum	Type C9200 / C9400 Magenta Drum
Okii C9200 / C9400 Yellow Drum	Type C9200 / C9400 Yellow Drum
Panasonic Laser	
Panafax UF745 / LS5	UG-3204
Panafax UF744 / UF788	UG-3309
Panafax UF550 / UF560 / UF770 / UF880 / UF885	UG-3313
Panafax UF585 / UF595	UG-3350
Panafax DX-600/UF-580/UF-585/UF-590/UF-595/UF-6100/UF-6300	UG-3380
Panafax UF7000 / UF8000 / UF9000	UG-5530
Panafax UF7100 / UF8100	UG-5545
PB Laser	
Pitney Bowes 9700	Pitney Bowes 9700
Pitney Bowes 9800	Pitney Bowes 9800
Pitney Bowes 9900	Pitney Bowes 9900
Ricoh Laser	
Ricoh 1700 / 1750 / BTBF900 (Drum)	339472 Master unit Type 70
Ricoh 1700 / 1750 / BTBF900 (Toner)	339474 Type 70
Ricoh 2700 / 3700 / 4700 / MV310	339481 Type 150
Ricoh Aficio SPC220N / SPC221N / SPC222DN	Ricoh SP C220 Black
Ricoh Aficio SPC220N / SPC221N / SPC222DN	Ricoh SP C220 Cyan
Ricoh Aficio SPC220N / SPC221N / SPC222DN	Ricoh SP C220 Magenta
Ricoh Aficio SPC220N / SPC221N / SPC222DN	Ricoh SP C220 Yellow
Ricoh SP C310HE	Ricoh SP C310HE Black
Ricoh SP C310HE	Ricoh SP C310HE Cyan
Ricoh SP C310HE	Ricoh SP C310HE Magenta
Ricoh SP C310HE	Ricoh SP C310HE Yellow
Ricoh SP1000E	Ricoh SP1000E

Ricoh 2400L / 2700L / 3700L	Type 12
Ricoh 1120L / 1160L	Type 1265
Ricoh 200L	Type 1430/35
Samsung Laser	
Samsung ML-1210	ML 1210D3
Samsung ML-1520	ML 1520D3
Samsung ML-1610	ML 1610
Samsung ML-1630	ML 1630
Samsung ML-1650D8	ML 1650D8
Samsung ML-1500 / ML-1510 / ML-1710 / ML-1750 / ML-1755	ML 1710 D3
Samsung ML-2010 / ML-2015 / ML-2510 / ML-2570 / ML-2571N	ML 2010
Samsung ML-3710ND / SCX-5737FW	ML 205L High Cap
Samsung ML-3710ND / SCX-5737FW	ML 205S Std Cap
Samsung ML-2150 / ML-2151	ML 2150D8
Samsung ML-2250 / ML-2251	ML 2250D5
Samsung ML-2510	ML 2510
Samsung ML-2550	ML 2550
Samsung ML-2850	ML 2850 Hi Cap
Samsung ML-2850A Std Cap	ML 2850A Std Cap
Samsung ML-3050	ML 3050 / ML 3051
Samsung ML-3060	ML 3060
Samsung ML-3470	ML 3470
Samsung ML-3560 / ML-3561N Std Cap	ML 3560 D6 / ELS Std Cap
Samsung ML-3560 / ML-3561N Hi Cap	ML 3560 DB / ELS Hi Cap
Samsung ML-4500 / ML-4500	ML 4500D3
Samsung ML-4550	ML 4550B
Samsung ML-5000	ML 5000
Samsung ML-5500	ML 5500
Samsung ML-6000	ML 6000
Samsung ML-1440 / ML-1450 / ML-6060	ML 6060 D6
Samsung ML-7000	ML 7000
Samsung ML-7300	ML 7300
Samsung ML-1910 / 1915 / 2525 / 2580 / SCX-4600 / 4623 / SF-650	MLT 1052L Hi Cap
Samsung ML-1910 / 1915 / 2525 / 2580 / SCX-4600 / 4623 / SF-650	MLT 1052S Std Cap
Samsung ML-1660 / ML-1665 / ML-1860 / ML-1865W / SCX-3205 / 3205W	MLT D1042S / ELS
Samsung ML-1640 / 2240	MLT D1082S / ELS
Samsung SCX-4300	MLT D1092S
Samsung SCX-4824 / 4825 / 4828 / ML-2855	MLT D2092L Hi Cap
Samsung SCX-4824 / 4825 / 4828 / ML-2855	MLT D2092S Std Cap
Samsung SCX-4200 Series	SCX 4200
Samsung SCX 4016 / 4116 / 4216 / SF-560 / 565p / 750	SCX 4216D3
Samsung SCX-4521	SCX 4521
Samsung SCX-4720	SCX 4720
Samsung SCX-4725	SCX 4725
Samsung SF-850	SCX 5312
Samsung SF-850	SCX 5312 Drum
Samsung SCX-6120	SCX 6120
Samsung SCX-6120	SCX 6120 Drum
Samsung SCX 6320	SCX 6320
Samsung SCX-6345	SCX 6345
Samsung SCX-6345	SCX 6345 Drum
Samsung SCX-5530FN	SCX D5530B Hi Cap
Samsung SCX-4100	SCX-4100D3
Samsung SF-5100 / SF-515	SF 5100D3
Samsung SF-560R	SF 560R
Samsung SF-5800	SF 5800
Samsung SF-6800	SF 6800
Samsung MSYS-6400 / MSYS-6500 / SF-6000 / SF-6100 / SF-6050	SF6061DRTD
Samsung Colors Laser	
Samsung CLP-300 / CLX 2160 / 2161K / 3160FN	CLP 300 Black
Samsung CLP-300 / CLX 2160 / 2161K / 3160FN	CLP 300 Cyan
Samsung CLP-300 / CLX 2160 / 2161K / 3160FN	CLP 300 Magenta

Samsung CLP-300 / CLX 2160 / 2161K / 3160FN	CLP 300 Yellow
Samsung CLP-500 / CLP-550	CLP 500 Black
Samsung CLP-500 / CLP-550	CLP 500 Cyan
Samsung CLP-500 / CLP-550	CLP 500 Magenta
Samsung CLP-500 / CLP-550	CLP 500 Yellow
Samsung CLP-510 Black	CLP 510 Black
Samsung CLP 510 Cyan	CLP 510 Cyan
Samsung CLP 510 Magenta	CLP 510 Magenta
Samsung CLP 510 Yellow	CLP 510 Yellow
Samsung CLP 350 Cyan	CLP C350A/ELS Cyan
Samsung CLP-600 / 650	CLP C600A Cyan
Samsung CLP-350 Black	CLP K350A/ELS Black
Samsung CLP 350 Magenta	CLP M350A/ELS Magenta
Samsung CLP-600 / 650	CLP M600A/SEE Magenta
Samsung CLP-600 / 650	CLP K600A Black
Samsung CLP 350 Yellow	CLP Y350A/ELS Yellow
Samsung CLP-600 / 650	CLP Y600A/SEE Yellow
Samsung CLP-610ND / 660ND / CLX 6200FX / CLX 6210FX / 6240FX	CLP C660A Cyan Std Cap
Samsung CLP-610ND / 660ND / CLX 6200FX / CLX 6210FX / 6240FX	CLP C660B/ELS Cyan Hi Cap
Samsung CLP-610ND / 660ND / CLX 6200FX / CLX 6210FX / 6240FX	CLP K660A Black Std Cap
Samsung CLP-610ND / 660ND / CLX 6200FX / CLX 6210FX / 6240FX	CLP K660B/ELS Black Hi Cap
Samsung CLP-610ND / 660ND / CLX 6200FX / CLX 6210FX / 6240FX	CLP M660A Magenta Std Cap
Samsung CLP-610ND / 660ND / CLX 6200FX / CLX 6210FX / 6240FX	CLP M660B/ELS Magenta Hi Cap
Samsung CLP-610ND / 660ND / CLX 6200FX / CLX 6210FX / 6240FX	CLP Y660A Yellow Std Cap
Samsung CLP-610ND / 660ND / CLX 6200FX / CLX 6210FX / 6240FX	CLP Y660B/ELS Yellow Hi Cap
Samsung CLP-320/320N/325/325W/CLX-3185/3185N/3185FN/3185FW	CLT 4072S/ELS Black
Samsung CLP-320/320N/325/325W/CLX-3185/3185N/3185FN/3185FW	CLT 4072S/ELS Cyan
Samsung CLP-320/320N/325/325W/CLX-3185/3185N/3185FN/3185FW	CLT 4072S/ELS Magenta
Samsung CLP-320/320N/325/325W/CLX-3185/3185N/3185FN/3185FW	CLT 4072S/ELS Yellow
Samsung CLP-310 / 315 / CLX 3170fn / 3175	CLT 4092 Back
Samsung CLP-310 / 315 / CLX 3170fn / 3175	CLT 4092 Black
Samsung CLP-310 / 315 / CLX 3170fn / 3175	CLT 4092 Cyan
Samsung CLP-310 / 315 / CLX 3170fn / 3175	CLT 4092 Cyan
Samsung CLP-310 / 315 / CLX 3170fn / 3175	CLT 4092 Magenta
Samsung CLP-310 / 315 / CLX 3170fn / 3175	CLT 4092 Magenta
Samsung CLP-310 / 315 / CLX 3170fn / 3175	CLT 4092 Yellow
Samsung CLP-310 / 315 / CLX 3170fn / 3175	CLT 4092 Yellow
Samsung CLP-620 Black	CLT 5082L Black Hi Cap
Samsung CLP-620 Cyan	CLT 5082L Cyan Hi Cap
Samsung CLP-620 Magenta	CLT 5082L Magenta Hi Cap
Samsung CLP-620 Yellow	CLT 5082L Yellow Hi Cap
Samsung CLP-620 Black	CLT 5082S Black Std Cap
Samsung CLP-620 Cyan	CLT 5082S Cyan Std Cap
Samsung CLP-620 Magenta	CLT 5082S Magenta Std Cap
Samsung CLP-620 Yellow	CLT 5082S Yellow Std Cap
Samsung CLP-770	CLT K6092S Black
Samsung CLP-770	CLT K6092S Cyan
Samsung CLP-770	CLT K6092S Magenta
Samsung CLP-770	CLT K6092S Yellow
Samsung CLX-K8380A Black	CLX 8380A Black
Samsung CLX-C8380A Cyan	CLX 8380A Cyan
Samsung CLX-M8380A Magenta	CLX 8380A Magenta
Samsung CLX-Y8380A Yellow	CLX 8380A Yellow
Samsung CLX-R838XC Cyan	CLX R838XC Cyan Drum
Samsung CLX-R838XK Black	CLX R838XK Black Drum
Samsung CLX-R838XM Magenta	CLX R838XM Magenta Drum
Samsung CLX-R838XY Yellow	CLX R838XY Yellow Drum
Samsung Intro Laser	
Samsung CLP-320/320N/325/325W/CLX-3185/3185N/3185FN/3185FW	CLT 4072S INTRO Black
Samsung CLP-320/320N/325/325W/CLX-3185/3185N/3185FN/3185FW	CLT 4072S INTRO Cyan
Samsung CLP-320/320N/325/325W/CLX-3185/3185N/3185FN/3185FW	CLT 4072S INTRO Magenta
Samsung CLP-320/320N/325/325W/CLX-3185/3185N/3185FN/3185FW	CLT 4072S INTRO Yellow

Samsung CLP-310 / 315 / CLX 3170fn / 3175	CLT 4092 Black INTRO
Samsung CLP-310 / 315 / CLX 3170fn / 3175	CLT 4092 Cyan INTRO
Samsung CLP-310 / 315 / CLX 3170fn / 3175	CLT 4092 Magenta INTRO
Samsung CLP-310 / 315 / CLX 3170fn / 3175	CLT 4092 Yellow INTRO
Xerox Laser	
Xerox WorkCentre PE120	Xerox 013R00606
Xerox Phaser 3400	Xerox 106R00461 Std Cap
Xerox Phaser 3400	Xerox 106R00462 Hi Cap
Xerox Pro 412 Copier	Xerox 106R00584
Xerox Workcentre M15 / M15i / Pro 312 / 412	Xerox 106R00586
Xerox Phaser 7750	Xerox 106R00652 Black
Xerox Phaser 7750	Xerox 106R00653 Cyan
Xerox Phaser 7750	Xerox 106R00654 Magenta
Xerox Phaser 7750	Xerox 106R00655 Yellow
Xerox Phaser 6250	Xerox 106R00668 Cyan Std Cap
Xerox Phaser 6250	Xerox 106R00669 Magenta Std Cap
Xerox Phaser 6250	Xerox 106R00670 Yellow Std Cap
Xerox Phaser 6250	Xerox 106R00671 Black Std Cap
Xerox Phaser 6250	Xerox 106R00672 Cyan Hi Cap
Xerox Phaser 6250	Xerox 106R00673 Magenta Hi Cap
Xerox Phaser 6250	Xerox 106R00674 Yellow Hi Cap
Xerox Phaser 6250	Xerox 106R00675 Black Hi Cap
Xerox Phaser 6100	Xerox 106R00676 Cyan Std Cap
Xerox Phaser 6100	Xerox 106R00677 Magents Std Cap
Xerox Phaser 6100	Xerox 106R00678 Yellow Std Cap
Xerox Phaser 6100	Xerox 106R00679 Black Std Cap
Xerox Phaser 6100	Xerox 106R00680 Cyan Hi Cap
Xerox Phaser 6100	Xerox 106R00681 Magenta Hi Cap
Xerox Phaser 6100	Xerox 106R00682 Yellow Hi Cap
Xerox Phaser 6100	Xerox 106R00684 Black Hi Cap
Xerox Phaser 3450 Series	Xerox 106R00687
Xerox Phaser 3450 Series	Xerox 106R00688
Xerox CopyCentre C20 / WorkCentre M20 / M20i	Xerox 106R01048
Xerox Phaser 6300	Xerox 106R01073 Cyan Std Cap
Xerox Phaser 6350	Xerox 106R01073 Std Cap Cyan
Xerox Phaser 6300	Xerox 106R01074 Magenta Std Cap
Xerox Phaser 6350	Xerox 106R01074 Std Cap Magenta
Xerox Phaser 6350	Xerox 106R01075 Std Cap Yellow
Xerox Phaser 6300	Xerox 106R01075 Yellow Std Cap
Xerox Phaser 6350	Xerox 106R01076 Std Cap Black
Xerox Phaser 7400	Xerox 106R01077 Cyan Hi Cap
Xerox Phaser 7400	Xerox 106R01078 Magenta Hi Cap
Xerox Phaser 7400	Xerox 106R01079 Yellow Hi Cap
Xerox Phaser 7400	Xerox 106R01080 Black Hi Cap
Xerox Phaser 6300	Xerox 106R01082 Cyan Hi Cap
Xerox Phaser 6300	Xerox 106R01083 Magenta Hi Cap
Xerox Phaser 6300	Xerox 106R01084 Yellow Hi Cap
Xerox Phaser 6300	Xerox 106R01085 Black Hi Cap
Xerox Phaser 6350	Xerox 106R01144 Hi Cap Cyan
Xerox Phaser 6350	Xerox 106R01145 Hi Cap Magenta
Xerox Phaser 6350	Xerox 106R01146 Hi Cap Yellow
Xerox Phaser 6350	Xerox 106R01147 Hi Cap Black
Xerox Phaser 3500VB / Phaser 3500VDN / Phaser 3500VN	Xerox 106R01148
Xerox Phaser 3500VB / Phaser 3500VDN / Phaser 3500VN	Xerox 106R01149 Hi Cap
Xerox Phaser 7400	Xerox 106R01150 Cyan Std Cap
Xerox Phaser 7400	Xerox 106R01151 Magenta Std Cap
Xerox Phaser 7400	Xerox 106R01152 Yellow Std Cap
Xerox Phaser 3117 / 3122	Xerox 106R01159
Xerox Phaser 6360	Xerox 106R01214 Cyan Std Cap
Xerox Phaser 6360	Xerox 106R01215 Magenta Std Cap
Xerox Phaser 6360	Xerox 106R01216 Yellow Std Cap
Xerox Phaser 6360	Xerox 106R01217 Black Std Cap

Xerox Phaser 6360	Xerox 106R01218 Cyan Hi Cap
Xerox Phaser 6360	Xerox 106R01219 Magenta Hi Cap
Xerox Phaser 6360	Xerox 106R01220 Yellow Hi Cap
Xerox Phaser 6360	Xerox 106R01221 Black Hi Cap
Xerox Phaser 6110	Xerox 106R01271 Cyan
Xerox Phaser 6110	Xerox 106R01272 Magenta
Xerox Phaser 6110	Xerox 106R01273 Yellow
Xerox Phaser 6110	Xerox 106R01274 Black
Xerox Phaser 6125	Xerox 106R01331 Hi Cap
Xerox Phaser 6125	Xerox 106R01332 Hi Cap
Xerox Phaser 6125	Xerox 106R01333 Hi Cap
Xerox Phaser 6125	Xerox 106R01334 Hi Cap
Xerox Phaser 3600VB	Xerox 106R01370 Std Cap
Xerox Phaser 3600VB	Xerox 106R01371 Hi Cap
Xerox Phaser 3250D	Xerox 106R01373 Std Cap
Xerox Phaser 3250D	Xerox 106R01374 Hi Cap
Xerox Phaser 6280	Xerox 106R01388 Cyan Std Cap
Xerox Phaser 6280	Xerox 106R01389 Magenta Std Cap
Xerox Phaser 6280	Xerox 106R01390 Yellow Std Cap
Xerox Phaser 6280	Xerox 106R01391 Black Std Cap
Xerox Phaser 6280	Xerox 106R01392 Cyan Hi Cap
Xerox Phaser 6280	Xerox 106R01393 Magenta Hi Cap
Xerox Phaser 6280	Xerox 106R01394 Yellow Hi Cap
Xerox Phaser 6280	Xerox 106R01395 Black Hi Cap
Xerox Phaser 3300MFP	Xerox 106R01411 Std Cap
Xerox Phaser 3300MFP	Xerox 106R01412 Hi Cap
Xerox Phaser 6121	Xerox 106R01463 Cyan Std Cap
Xerox Phaser 6121	Xerox 106R01464 Magenta Std Cap
Xerox Phaser 6121	Xerox 106R01465 Yellow Std Cap
Xerox Phaser 6121	Xerox 106R01466 Cyan Hi Cap
Xerox Phaser 6121	Xerox 106R01467 Magenta Hi Cap
Xerox Phaser 6121	Xerox 106R01468 Yellow Hi Cap
Xerox Phaser 6121	Xerox 106R01469 Black Hi Cap
Xerox Phaser 6140	Xerox 106R01477 Cyan
Xerox Phaser 6140	Xerox 106R01478 Magenta
Xerox Phaser 6140	Xerox 106R01479 Yellow
Xerox Phaser 6140	Xerox 106R01480 Black
Xerox Phaser 8550	Xerox 108R00669 / Cyan
Xerox Phaser 8550	Xerox 108R00670 / Magenta
Xerox Phaser 8550	Xerox 108R00671 Yellow
Xerox Phaser 8550	Xerox 108R00672 / Black
Xerox Phaser 8560	Xerox 108R00723 Cyan
Xerox Phaser 8560	Xerox 108R00724 Magenta
Xerox Phaser 8560	Xerox 108R00725 Yellow
Xerox Phaser 8560	Xerox 108R00727 Black
Xerox Phaser 3635MFP	Xerox 108R00792 Metered/Pagepack
Xerox Phaser 3635MFP	Xerox 108R00793
Xerox Phaser 3635MFP	Xerox 108R00795
Xerox Phaser 3120 / Phaser 3130	Xerox 109R00725
Xerox Phaser 3150	Xerox 109R00746 / 109R00747
Xerox DocuPrint N2025 / N2825	Xerox 113R00443
Xerox DocuPrint N2125	Xerox 113R00445
Xerox DocuPrint N2125	Xerox 113R00446 Hi Cap
Xerox Phaser 4500	Xerox 113R00656 Std Cap
Xerox Workcentre M15 / M15i / Pro 312 / 413	Xerox 113R00663 Drum
Xerox Phaser 6120	Xerox 113R00689 Cyan Std Cap
Xerox Phaser 6120	Xerox 113R00690 Yellow Std Cap
Xerox Phaser 6120	Xerox 113R00691 Magenta Std Cap
Xerox Phaser 6120	Xerox 113R00692 Black Hi Cap
Xerox Phaser 6120	Xerox 113R00693 Cyan Hi Cap
Xerox Phaser 6120	Xerox 113R00694 Yellow Hi Cap
Xerox Phaser 6120	Xerox 113R00695 Magenta Hi Cap

Xerox Phaser 4500	Xerox 113R00703 Hi Cap
Xerox Phaser 4510	Xerox 113R00711 Std Cap
Xerox Phaser 4510	Xerox 113R00712 Hi Cap
Xerox Phaser 6180	Xerox 113R00719 Std Cap C
Xerox Phaser 6180	Xerox 113R00720 Std Cap M
Xerox Phaser 6180	Xerox 113R00721 Std Cap Y
Xerox Phaser 6180	Xerox 113R00722 Std Cap B
Xerox Phaser 6180	Xerox 113R00723 Hi Cap C
Xerox Phaser 6180	Xerox 113R00724 Hi Cap M
Xerox Phaser 6180	Xerox 113R00725 Hi Cap Y
Xerox Phaser 6180	Xerox 113R00726 Hi Cap B
Xerox Phaser 3200MFP	Xerox 113R00730 (D3) Hi Cap
Xerox Phaser 3200MFP	Xerox 113R00735 Std Cap

